

PHILIPS

Bowl

CP1328



to replace your current Bowl

for your ingredients

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1387/00, HR1388/50, HR1388/80

