



Basket for the tea or teabags in your your teamake

Check compatibility data

Did you know that green tea needs another preparation than for instance herbal tea? Your teamaker takes care of it all. The detachable filter basket can be used to put the tea or teabags in.

Ease of using Philips spare parts

• Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Replaceable part

For kitchen appliance model:: HD7311/60, HD7310/60

© 2020 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2020-07-15 Version: 4.0.1

