

PHILIPS

Pusher

CP0675



to replace your current pusher

you need this pusher to press your ingredients down.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1886/xx, HR1887/xx, HR1888/xx, HR1889/xx

