



Philips
Rice cooker

HD4723/54

5.5-cup



HD4723

More life in every bowl

Smart and automatic rice cooking

Nutrition is the most important element to keep healthy. Philips' rice cookers come with automatic cooking programs that better preserve the freshness and nutrients in every bowl of rice.

Smart and automatic cooking

- Top and bottom heating cooks rice more evenly
- Automatic keep warm keeps rice fresh for 12 hours

Easy to operate

- One touch button for easy control

The ultimate in convenience

- Advanced lid design for easy and safe access
- Easy-to-clean non-stick inner pot
- Swing handle for easy carrying
- Easy-to-read water level indicator
- Detachable power cord for convenient storage

PHILIPS
sense and simplicity

Specifications

General specifications

- Top and bottom heating cooks rice more evenly
- 12 hours keep warm
- One-touch operation
- Advanced lid design
- Swing handle for easy carrying
- easy clean non-stick inner pot
- Detachable power cord for convenient storage
- Water level indicator

Technical specifications

- Capacity: 1.0/5.5 Litres/cups
- Inner pot capacity: 3 litres
- Cord length: 1.0 m
- Voltage: 220-240 V

- Frequency: 50/60 Hz
- Wattage: 500 W

Design specifications

- Materials of main body: body — plastic/metal; lid — plastic
- Available colour(s): golden metallic
- Weight of the appliance: 2.7 kg
- Weight (incl. packaging): 4.1 kg

Accessories

- Plastic steam tray
- Rice scoop
- Measuring cup

Highlights

Top and bottom heating cooks rice more evenly



Top and bottom heating cooks rice more evenly

Automatic 12 hours keep warm

Use the keep warm function to keep rice warm for a longer period of time. When the cooking process is finished, the rice cooker automatically switches to the keep warm mode

One touch button

One-press button to control cooking or keep warm, with clear light on the panel to show cooking status

Advanced lid design

Cool surface, easy to access with one touch button

non-stick inner pot




Specially coated with non-stick material that is more durable and easy to clean

Swing handle

Convenient and safe handle for carrying the rice cooker away from the kitchen, or for serving rice in the dining room

water level indicator



Clear water level marking shows capacity and rice-water ratio

Detachable power cord for convenient storage

Detachable power cord for convenient storage



Issue date 2009-07-31

Version: 4.1.1

12 NC: 0000 000 00000

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com