

PHILIPS

Whisk (1 pcs)

CP9581



to replace your current whisk

Single whisk accessory for Philips hand blender for whipping cream, mayonnaise, pancake batter and more. Makes your hand blender multifunctional and versatile.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1610/00, HR1610/01, HR1611/01, HR1613/03, HR1614/01, HR1615/00, HR1615/90, HR1615/91, HR1617/00, HR1617/01, HR1617/03, HR1617/90, HR1619/00

Fits product types:: HR1600/00, HR1600/01, HR1600/09, HR1601/00, HR1601/19, HR1602/00, HR1602/01, HR1603/00, HR1604/00, HR1604/01, HR1604/03, HR1604/09, HR1604/90, HR1605/00, HR1605/01, HR1606/00, HR1607/00, HR1608/00, HR1608/03, HR1609/00, HR1609/03, HR1621/00, HR1621/05, HR1623/00, HR1623/04, HR1625/00, HR1627/00, HR1627/05, HR1628/00, HR1633/80, HR1634/80, HR1635/80, HR1636/80, HR1636/81, HR1637/80, HR1638/90, HR1639/90

