

Philips Toaster oven

HD4493/08

Delicious hot food easily

30-minute timer

A toaster oven designed to help you make delicious food and snacks every time. Toasts and warms, and has a lot of features that make it easy to get good food. Includes 30-minute timer, crumb tray and baking tray.

Delicious food

- Toasts or warms food and snacks
- 30-minute timer shuts off the oven once ready

Easy to experience

- Large square baking tray (230 x 230 mm)
- Removable crumb tray for easy cleaning
- Ready bell sounds when food is ready
- Detachable grid

Safe to use

• On/off light



Specifications

General specifications • Non slip feet

Technical specifications

- Capacity: 9 | Effective capacity: 5.7 | Power: 900 W
- · Cord length: 1.0 m
- Heating elements: Quartz (2x)

- Voltage: 220-240 V
 Frequency: 50-60 Hz

Design specifications

- Materials: Metal housing, plastic knobs/handles (PBT)
- Àvailable color(s): Pearl white/grey/blue /08

Accessories included

• Baking tray: 230 x 230 mm

HD4493/08

Highlights

Function

Toasts or warms food and snacks.

30-minute timer



30-minute timer shuts off the oven once ready.

Removable crumb tray



Is easy to clean thanks to its removable crumb tray.

Ready bell Ready bell sounds when food is ready.



Issue date 2010-12-08

© 2010 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.1.1

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 0000 000 00000 www.philips.com