



Indispensable for using your mixer

Find matching products on the specifications tab

A pair of wire beaters that fits with your Philips hand mixer. Having an extra pair might be handy: when one's in the dishwasher, you can use the other!

Ease of using Philips spare parts

• Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types: HR1560/40, HR1560/20, HR1560/53, HR1560/55, HR1560/80, HR1560/81, HR1561/55, HR1561/80, HR1561/60, HR1561/63, HR1570/90, HR1570/30, HR1570/00, HR1571/90, HR1571/30, HR1571/00, HR1571/01
Fits product type:: HR1560/41

© 2020 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2020-06-09 Version: 2.0.1

EAN: 08 71010 35486 07

www.philips.com

