

Philips Rice cooker HD4728/54 10 cups



# More life in every bowl

## Smart and automatic rice cooking

Nutrition is the most important element to keep healthy. Philips' rice cookers come with automatic cooking programs that better preserve the freshness and nutrients in every bowl of rice.

## Smart and automatic cooking

- Top and bottom heating cooks rice more evenly
- Automatic keep warm keeps rice fresh for 12 hours

## Easy to operate

• One touch button for easy control

## The ultimate in convenience

- Advanced lid design for easy and safe access
- Easy-to-clean non-stick inner pot
- Swing handle for easy carrying
- Easy-to-read water level indicator
- Detachable power cord for convenient storage



## Specifications

### **General specifications**

- Top and bottom heating cooks rice more evenly
- 12 hours keep warm
- One-touch operation
- Easy clean non-stick innerpot
- · Advanced lid design
- · Swing handle for easy carrying
- · Detachable power cord for convenient storage
- Water level indicator

#### **Technical specifications**

- Capacity: 1.8/10 Litres / cups
- Inner pot capacity: 5 Litres
- Cord length: 1.0 m
- Voltage: 220-240 V

- Frequency: 50/60 Hz
  - Wattage: 700 W

## **Design specifications**

- Materials of main body: body-plastic/metal; lidplastic
- Available color(s): golden metallic
- Weight appliance: 3.4 kg
- Weight (incl. packaging): 5.0 kg

### Accessories

- · Plastic steam tray
- Rice scoop Measuring cup

## 1D4728/54

## Highlights

## Top and bottom heating cooks rice

more evenly Top and bottom heating cooks rice more evenly

## Automatic 12 hours keep warm

Use the keep warm function to keep rice warm for a longer period of time. When the cooking process is finished, the rice cooker automatically switches to the keepwarm mode

#### **One touch button**

One press button to control cook or keep warm, with clear light on the panel to show cooking status

## Advanced lid design

Cool surface, easy to access with one touch button

#### non-stick inner pot




Specially coated with the non-stick material which is more durable and easy to clean

### Swing handle

Convenient and safe to carry the rice cooker away from the kitchen, or to serve rice in dinning room

#### water level indicator



Clear water level marking shows capacity and ricewater ratio

Detachable power cord for convenient storage

Detachable power cord for convenient storage



Issue date 2011-05-31

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 4.1.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

www.philips.com

12 NC: 0000 000 00000