

PHILIPS

Pusher

black

CP0434



to replace your current pusher

you need the pusher to pull down your ingredients

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: HR1916/xx, HR1919/xx, HR1920/xx, HR1921/xx, HR1922/xx, HR1925/xx

