

PHILIPS

ON/OFF Knob

Premium Compact

Black

CP0354



Replace your current on/off knob

This knob is needed for turning your Airfryer on and off.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product family: HD972x/xx, HD962x

