



Holds two coffee pods in your SENSEO@

Please check specifications for compatible products

This pod holder contains the coffee pods you use in your SENSEO® coffee machine. When the holder is covered with the top of your SENSEO®, your coffee pods are at the correct pressure for optimum-tasting coffee. Suitable for two pods.

Ease of using Philips spare parts

 ${\boldsymbol{\cdot}}$ Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types: HD7820/31, HD7820/70, HD7820/71, HD7823/50, HD7823/73, HD7823/80, HD7824/80, HD7824/81, HD7841, HD7842, HD7843
Fits product types: HD7824/50, HD7824/60, HD7824/61, HD7824/63, HD7824/51, HD7824/53

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-12 Version: 4.0.1

