



© 2018 Koninklijke Philips N.V.
All rights reserved
保留所有权利
4222.003.4296.4 (6/8/2018)
> 75% 循环再造纸
保留备用



>75% recycled paper
>75% papier recyclé

English

Important safety information

Read this important information carefully before you use the appliance and save it for future reference.

Danger

- Do not immerse the robot or the adapter in water or any other liquid.
- Do not use the robot on wet floors or in places where there is a risk of contact with water or immersion in water.
- Never let the robot operate on or near flammable substances and do not allow it to pick up ashes until they are cold.
- Do not use the robot in humid surroundings like bathrooms.
- Do not pour any liquid into the openings of the robot.

Warning

- Check if the voltage indicated on the adapter corresponds to the local mains voltage before you connect the adapter.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Do not use the robot if the adapter or the robot itself is damaged or if the robot is not complete.
- If the mains cord is damaged, you must have it replaced by Philips, a service center authorized by Philips or similarly qualified persons in order to avoid a hazard.
- This robot is designed for indoor use only. Keep all doors leading outside closed.
- Do not use the robot in hazardous areas such as close to fireplaces, showers or swimming pools.
- This robot is better suited for cleaning hard floors. Its performance on soft floors can be somewhat limited.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep pets away from the robot. Do not let pets sit or stand on the robot.
- Keep loose clothing, hair and body parts away from the brushes of the robot.
- Remove all fragile and light objects from the floor and make sure the robot does not get entangled in the pull cords of blinds or curtains.
- Do not let the robot move over the mains cords of other appliances or other cables as this may cause a hazard.
- Stop the robot if a dangerous situation occurs or if the robot behaves abnormally or gives off an abnormal smell.
- To prevent damage, do not use the robot if the filter is not present in the dust container or has not been placed properly in the dust container.
- Do not cover the robot or block the ventilation openings when the robot is cleaning or charging. This may cause the robot to overheat.
- Do not store the robot at a temperature above 60°C or below -10°C.
- Do not use the robot in a room with a temperature above 45°C.
- The rechargeable battery may only be replaced by qualified service engineers. Take the robot to an authorized Philips service center to have the battery replaced when you can no longer recharge it or when it runs out of power quickly.
- Always return the appliance to an authorized Philips service center for examination or repair. Repair by unqualified persons could cause an extremely hazardous situation for the user.
- Do not incinerate, disassemble or expose the robot to temperatures above 60°C. The rechargeable battery may explode if overheated.

Caution

- The robot is fitted with drop-off sensors in the bottom. These drop-off sensors are used to detect and avoid height differences. In some cases, the drop-off sensors may not detect a staircase or other height difference in time. The circumstances in your home (e.g. the light in the room, the colour or type of your floor) can affect how well or fast the drop-off sensors react. Therefore monitor the robot carefully, especially the first few times you use it and when you operate it near a staircase or another height difference.
- Do not put any tape or stickers over the drop-off sensors and make sure you clean the drop-off sensors regularly. If the drop-off sensors are covered or dirty, the robot is unable to detect a staircase or other height difference.
- When you use the robot to vacuum fine sand, lime, cement dust and similar substances, the pores of the filter become clogged.
- Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.
- Do not touch the mains plug with wet hands.
- Only use the adapter supplied to charge the appliance.
- Unplug the docking station or the adapter if you are not going to use the robot for some time.
- Do not use the robot on high-pile carpets or on rugs with tassels.

- Do not clean the filter and the filter unit with water. You can rinse the dust container under a lukewarm tap. Make sure that the dust container is dry before you reinsert the filter unit. Do not clean the dust container in the dishwasher.

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Ordering accessories

To buy accessories or spare parts, visit www.shop.philips.com/service or go to your Philips dealer. You can also contact the Philips Consumer Care Center in your country (see the international warranty leaflet for contact details).

Recycling

- Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.
- This product contains a built-in rechargeable battery which shall not be disposed of with normal household waste. Please take your product to an official collection point or a Philips service center to have a professional remove the rechargeable battery.
- Follow your country's rules for the separate collection of electrical and electronic products and rechargeable batteries. Correct disposal helps prevent negative consequences for the environment and human health.

Removing the rechargeable battery

Only remove the rechargeable battery when you discard the product. Before you remove the battery, make sure that the product is disconnected from the wall socket and that the battery is completely empty.

Take any necessary safety precautions when you handle tools to open the product and when you dispose of the rechargeable battery.

Warranty and support

If you need information or support, please visit www.philips.com/support or read the international warranty leaflet.

Your robot vacuum cleaner has been designed and developed with the greatest possible care. In the unfortunate case that your robot needs repair, the Consumer Care Centre in your country will help you by arranging any necessary repairs in the shortest possible time and with maximum convenience. If there is no Consumer Care Centre in your country, go to your local Philips dealer.

简体中文

重要安全信息

使用产品之前，请仔细阅读本重要信息，并妥善保管以供日后参考。

危险

- 不要将扫地机器人（飞利浦自动充电式吸尘器）或适配器浸入水或任何其他液体中。
- 切勿在湿地板上或存在接触水或浸入水中的危险地方使用扫地机器人。
- 切勿让扫地机器人在易燃物质上或其附近运转，也不要让它在灰烬冷却前清扫灰烬。
- 切勿在浴室等潮湿的地方使用扫地机器人。
- 切勿将任何液体倒入扫地机器人的开口中。

警告

- 在将适配器连接电源前，务必检查当地的电压是否与电源适配器所标电压一致。
- 清洁或维护产品之前，必须先从插座拔掉插头。
- 如果适配器或吸尘器本身受损或吸尘器不完整，切勿使用吸尘器。
- 如果电源线损坏，为了避免危险，必须由飞利浦、飞利浦特约维修中心或有同等维修资格的专业人员进行更换。
- 根据设计，本吸尘器只能在室内使用。所有通向室外的门均需保持关闭。
- 切勿在危险区域（例如在火炉、淋浴或泳池附近）使用吸尘器。
- 本吸尘器更适于清洁硬地板。在软地板上，其性能可能会受到一定程度的限制。
- 产品不建议由有肢体、感官或精神能力缺陷或缺乏使用经验和知识的人（包括儿童）使用，除非有负责他们安全的人对他们进行与产品使用有关的监督或指导。
- 请照顾好儿童，本产品不能用于玩耍。
- 确保宠物远离吸尘器。切勿让宠物坐在或站在吸尘器上。
- 确保宽大的衣服、毛发和身体部位远离吸尘器的毛刷。
- 清除地板上的所有易碎物品和重量较小的物体，并确保百叶窗或窗帘的拉线不会缠绕吸尘器。
- 切勿让吸尘器在其它产品的电源线或其它线缆上移动，否则可能会引发危险。
- 如果发生危险情况，或吸尘器行为异常或发出异味，请关闭吸尘器。
- 为防止损坏，如果滤网在集尘桶中不存在或没有正确放置在集尘桶中，切勿使用吸尘器。
- 当吸尘器正在清洁或充电时，切勿覆盖吸尘器或堵塞通风口，否则可能导致吸尘器过热。
- 切勿将吸尘器存放在 60° C 以上或 -10° C 以下的环境中。
- 切勿在 45° C 以上的房间中使用吸尘器。
- 只有具备资格的服务工程师才能更换充电电池。当充电电池无法继续充电或耗电很快时，请将吸尘器送往授权的飞利浦服务中心，以更换电池。
- 本产品应送往授权的飞利浦服务中心检查或修理。由不具备资格的人员进行修理可能会将用户置于极度危险的境地。
- 切勿焚烧、拆卸吸尘器或者将其暴露在高于 60° C 的环境中。如果过热，充电电池可能会爆炸。

警告

- 吸尘器底部安装了五个跌落传感器。这些跌落传感器用于检测并避开有高度差的地方。在某些情况下，跌落传感器可能无法及时检测到楼梯或其他有高度差的地方。您的居室环境（如房间灯光、地板颜色或类型）可能会影响跌落传感器的反应灵敏度和速度。因此，应密切监控吸尘器的工作状况，在最初几次使用以及在楼梯或其他有高度差的地方附近使用时尤为如此。
- 切勿在跌落传感器上放置任何胶带或标签，并确保定期清洁跌落传感器。如果跌落传感器被覆盖或变脏，吸尘器将无法检测楼梯或其他有高度差的地方。
- 在使用吸尘器清洁细沙、石灰、水泥灰和类似物质时，滤网孔会被堵塞。
- 切勿使用钢丝球、研磨性清洁剂或腐蚀性液体（例如汽油或丙酮）来清洁本产品。
- 请勿用湿手触摸电源插头。
- 为产品充电，须用随产品提供的电源适配器。
- 如果打算一段时间内不使用吸尘器，请拔下底座或适配器插头。
- 切勿在长毛绒地毯或带流苏的地毯上使用吸尘器。
- 请勿用水清洁过滤网和滤网部件。您可以在微温水龙头下冲洗集尘桶。重新装入滤网部件之前，请确保集尘桶是干燥的。切勿在洗碗机中清洗集尘桶。

电磁场 (EMF)

本 Philips 产品符合所有有关暴露于电磁场的适用标准和法规。

回收

- 弃置本产品时，请不要将其与一般生活垃圾放在一起，应将其交给政府指定的回收中心。这样做将有利于环保。
- 此产品包含内置充电电池；请勿将充电电池与一般生活垃圾一起弃置。请您将产品送到官方收集中心或飞利浦服务中心，请专业人士移除充电电池。
- 遵循您的国家/地区有关分类回收电子电气产品和充电电池的规定。正确弃置产品有助于避免对环境和人类健康造成不良后果。

拆下充电电池

必须在丢弃本产品前拆下充电电池。卸下电池之前，请确保本产品与电源断开连接并且电池电量已耗尽。

当您使用工具打开本产品时以及在您弃置充电电池时，请采取必要的安全保护措施。

产品中有害物质的名称及含量						
部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
充电式吸尘器	X	O	O	O	O	O
电源适配器	X	O	O	O	O	O

本表格依据SJ/T 11364的规定编制。
O: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

- 该表格中所显示的“有害物质”在产品正常使用情况下不会对人身和环境产生任何伤害。
- 该表格中所显示的“有害物质”及其存在的部件向消费者和回收处理从业者提供相关物质的存在信息，有助于产品废弃时的妥善处理。

订购配件

要购买附件或备件，请访问 www.shop.philips.com/service 或联系您的飞利浦经销商。您还可以联系所在国家/地区的飞利浦客户服务中心（请参阅全球保修卡了解详细联系信息）。

保修和支持

如需信息或支持，请访问 www.philips.com/support 或阅读国际保修卡。

您的扫地机器人经过精心设计和开发。如果出现意外，扫地机器人需要维修，您所在国家/地区的客户服务中心会在最短时间内帮您安排必要的维修服务，尽可能地为您提供便利。如果您所在的国家/地区没有飞利浦客户服务中心，请向当地的飞利浦经销商求助。

<p>PHILIPS</p> <p>产品： 飞利浦自动充电式吸尘器 型号： FC8794 额定电压： 220V~ 额定频率： 50Hz 额定输入电流： 0.5 A最大 生产日期： 请见产品本体 产地： 中国江苏苏州</p> <p>飞利浦（中国）投资有限公司 上海市静安区灵石路718号A1幢 全国顾客服务热线：4008 800 008</p> <p>本产品根据国标 GB4706.1-2005、GB4706.7-2014、GB4343.1-2009及 GB17625.1-2012制造</p>	<p>PHILIPS</p> <p>产品： 飞利浦自动充电式吸尘器 型号： FC8795 额定电压： 220V~ 额定频率： 50Hz 额定输入电流： 0.5 A最大 生产日期： 请见产品本体 产地： 中国江苏苏州</p> <p>飞利浦（中国）投资有限公司 上海市静安区灵石路718号A1幢 全国顾客服务热线：4008 800 008</p> <p>本产品根据国标 GB4706.1-2005、GB4706.7-2014、GB4343.1-2009及 GB17625.1-2012制造</p>
---	---

<p>PHILIPS</p> <p>产品： 飞利浦自动充电式吸尘器 型号： FC8794 额定电压： 220V~ 额定频率： 50Hz 额定输入电流： 0.5 A最大 生产日期： 请见产品本体 产地： 中国江苏苏州</p> <p>飞利浦（中国）投资有限公司 上海市静安区灵石路718号A1幢 全国顾客服务热线：4008 800 008</p> <p>本产品根据国标 GB4706.1-2005、GB4706.7-2014、GB4343.1-2009及 GB17625.1-2012制造</p>	<p>PHILIPS</p> <p>产品： 飞利浦自动充电式吸尘器 型号： FC8792 额定电压： 220V~ 额定频率： 50Hz 额定输入电流： 0.5 A最大 生产日期： 请见产品本体 产地： 中国江苏苏州</p> <p>飞利浦（中国）投资有限公司 上海市静安区灵石路718号A1幢 全国顾客服务热线：4008 800 008</p> <p>本产品根据国标 GB4706.1-2005、GB4706.7-2014、GB4343.1-2009及 GB17625.1-2012制造</p>
---	---

保留备用

发行日期：6/8/2018