

PHILIPS

Pusher

CP9546



to replace your current pusher

You need this part to pull down all your ingredients.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1871/00

Fits product types:: HR1870/05, HR1870/10, HR1870/70, HR1871/05, HR1871/10, HR1871/11,

HR1871/15, HR1871/70, HR1872/30, HR1873/00, HR1873/72, HR1874/70, HR1876/70, HR1871/71, HR1874/74, HR1869/00, HR1869/01, hr1869/05, HR1869/30, HR1869/31, HR1869/35, HR1869/60, HR1869/61, HR1869/70, HR1869/71, HR1869/80, HR1870/00, HR1870/15, HR1874/00

