PHILIPS

Handheld steam cleaner

SteamCleaner Multi

950 W

2 microfiber pads

Precision nozzle



FC7008/31



Always hygienically clean surfaces with steam

Clean tough stains, kill bacteria without chemicals

Philips SteamCleaner Multi cleans to tough stains and grease with steam. Enjoy hygienic cleaning results using only water steam kills up to 99,9% bacteria. The steam nozzle reaches all corners and the microfiber pad lifts and absorbs dirt.

100% chemical free cleaning

 $\boldsymbol{\cdot}$ No detergent needed, no residues left on the surfaces

Easy to use

- · Light weight, compact and easy to store
- · Indicates when ready to use
- 2 Microfiber pads included

Hygienic cleaning results

 ${}^{\centerdot}$ Steam kills up to 99.9% of germs and bacteria

Maximum reach to clean all nooks and corners

- · Triangular steam nozzle for all areas
- · Precision steam nozzle for tight corners

Removes even the toughest stains

- · Clean tough stains and oil from smooth surfaces easily
- · Washable and durable microfiber pads

Highlights

100% chemical free cleaning



Philips SteamCleaner Multi uses only water, it does not leave any kind of residues on your surfaces.

Removes germs and bacteria

Enjoy hygienic cleaning results with Philips SteamCleaner Multi. The SteamCleaner Multi kills up to 99,9% of germs and bacteria located on the surfaces without chemicals and only the use of water.

Washable microfiber pads

2 washable and durable microfiber pads are included. The soft microfiber material gently loosens, lifts, and absorbs dust and dirt. Removing dirt effectively and gently. The microfiber pads are machine-washable and easy to attach and remove.

Easy to use

The SteamCleaner Multi is small and compact, easy to store and always at hand. It is lightweight and makes even longer cleaning sessions less tiresome

Indicates when ready to use

The indication light turns white when is heating up, and the blue light starts blinking when the appliance is ready to steam.

SteamCleaner Multi is ready to use in less than 45 sec delivering you continuous steam throughout the cleaning process.

Super absorbent microfiber pad

The microfiber pads are specially designed to lift and absorb all dirt and dust from the surfaces while you are steaming, for one-step cleaning without effort.

Cleans even the toughest dirt



Steam at high temperature easily dissolves grease and dirt. Steam is known as a powerful method to loosen all kinds of stains and dirt.

Maximum reach

Clean smooth surfaces with the triangular steam nozzle and the attached microfiber pad. In one stroke you remove dirt and stains. Thanks to its triangular shape you can both clean surfaces as well as reach into corners with the pointed tip.

Precision nozzle for corners

The precision steam nozzle is specially designed with a unique shape to reach into those tight and hard-to-reach areas where you cannot reach with traditional tools, such as ventilation hoods.

Specifications

Design

Color: Bright green

Performance

Input power (max): 950 W

Usability

Cord length: 2.5 m

Weight and dimensions

Weight of product: 0.7 kg

Nozzles and accessories

Accessories included: 2 microfiber pads Cleaning: Washable microfiber pad Steam nozzle: Precision steam nozzle, Triangular steam nozzle

Steam Management

Heating-up time: <45 sSteam temp. at nozzle: $>100 \,^{\circ}\text{C}$ Chemical free cleaning: $100 \,^{\circ}\text{C}$

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-02-12 Version: 1.0.1

