



Delicious hot food easily

45-minute timer, temperature selector

The multi-purpose toaster oven that does almost anything! Bakes, broils, toasts and warms, with lots of easy-cook features for delicious results every time. Includes adjustable thermostat, 45-minute timer, baking tray and crumb tray.

Delicious food

- · Bakes, broils, toasts, or warms food and snacks
- Adjustable thermostat for optimal food results (max 230 °C)
- · 45-minute timer shuts off the oven once ready

Easy to experience

- · Ready bell sounds when food is ready
- · Removable crumb tray for easy cleaning
- · Large square baking tray, non stick coated (230 x 230 mm)
- · Detachable grid

Safe to use

· On/off light

Highlights

Multifunction



Bakes, broils, toasts or warms food and snacks

Adjustable thermostat

Adjustable thermostat for optimal food results (max 230 $^{\circ}$ C)

45-minute timer



45-minute timer shuts off the oven once ready

Ready bell

Ready bell sounds when food is ready

Removable crumb tray



Is easy to clean thanks to its removable crumb

Specifications

General specifications

Non slip feet

Technical Specifications

Capacity: 9 l

Effective capacity: 5.7 l Power: 1100 W

Cord length: 1.0 m

Heating elements: Quartz (2x)

Voltage: 220-240 V Frequency: 50-60 Hz

Design specifications

Materials: Metal housing, plastic

knobs/handles (PBT)

Available colors: Steel silver/charcoal grey

/25

Accessories included

Baking tray: 230 x 230 mm

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-07 Version: 3.1

