



Catches the crumbs in your toaster

Check compatibility data

This crumb tray collects the crumbs in your toaster. Easily detachable, so easy to fill up, empty and clean!

Ease of using Philips spare parts

• Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HD2636/20

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-12 Version: 2.0.1

