

PHILIPS

Pusher

CP9787



to replace your current pusher

you need this pusher to press your ingredients down.

Ease of using Philips spare parts

- Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: HR1894/8x, HR1895/7x, HR1895/8x, HR1896/7x, HR1897/3x, HR1899/2x

