

PHILIPS

Pulp container

black

CP0443



to replace your current pulp container

The round shape, without nooks and crannies, means that leftovers are collected in the pulp container.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product type:: HR1916/xx, HR1919/xx, HR1920/xx, HR1921/xx, HR1922/xx, HR1925/xx

