



# Delicious hot food easily

### 45-minute timer, temperature selector

The multi-purpose toaster oven that does almost anything! Bakes, broils, toasts and warms, with lots of easy-cook features for delicious results every time. Includes adjustable thermostat, 45-minute timer, baking tray and crumb tray.

#### Delicious food

- · Bakes, broils, toasts, or warms food and snacks
- Adjustable thermostat for optimal food results (max 230 °C)
- · 45-minute timer shuts off the oven once ready

### Easy to experience

- · Ready bell sounds when food is ready
- · Removable crumb tray for easy cleaning
- · Large square baking tray, non stick coated (230 x 230 mm)
- · Detachable grid

#### Safe to use

· On/off light

# Highlights

#### Multifunction



Bakes, broils, toasts or warms food and snacks

#### **Adjustable thermostat**

Adjustable thermostat for optimal food results (max 230  $^{\circ}$ C)

#### 45-minute timer



45-minute timer shuts off the oven once ready

#### Ready bell

Ready bell sounds when food is ready

#### Removable crumb tray



Is easy to clean thanks to its removable crumb

# Specifications

#### **General specifications**

Non slip feet

#### **Technical Specifications**

Capacity: 9 l

Effective capacity: 5.7 l Power: 1100 W

Cord length: 1.0 m

Heating elements: Quartz (2x)

Voltage: 220-240 V Frequency: 50-60 Hz

#### **Design specifications**

Materials: Metal housing, plastic

knobs/handles (PBT)

Available colors: Steel silver/charcoal grey

/25

### **Accessories included**

Baking tray: 230 x 230 mm

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-07 Version: 3.1

