

PHILIPS

Dust bag holder

Original part

Performer Active

CP0485



Dust bag holder replacement for Performer Active

Find matching products on the specifications tab

Original dust bag holder replacement for the Performer Active range.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

Specifications

Suitable for

5000 Series, PerformerActive: FC8650 - FC8659, FC8575/09..FC8579/09, FC8585/01, FC8588/01, FC8589/01, FC8592/91, FC8593/91, FC8660..FC8664
PerformerActive ECO: FC8520 - FC8528

