


# PHILIPS

Potato masher  
paddle

CP9722



## to replace your current masher paddle

With the masher accessory for the Philips hand blender you can mash potatoes silky smooth. Also other vegetables can be mashed or pureed.

### **Ease of using Philips spare parts**

- Easily renew your product with original Philips parts

# Highlights

## Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

# Specifications

## Replaceable part

**Fits product types::** HR1640/0x, HR1641/0x, HR1642/0x, HR1643/0x, HR1644/0x, HR1645/0x, HR1646/0x, HR1647/0x, HR1670/0x, HR1671/0x, HR1672/0x, HR1673/0x, HR1674/0x, HR1675/0x, HR1676/0x, HR1677/0x

