



Have it your way, exactly your way

Set the timer for delicious sandwiches

Have your sandwiches just the way you want them. Place any sandwich you like between the large plates and select your preferred timing. The non-stick, removable, dishwasher safe plates make cleaning easier than ever before.

Delicious sandwiches

- · Fits all kinds of sandwiches thanks to the large plates
- · Quick and delicious results thanks to the 900 Watt of power

Exactly the way you like

- Digital timer with audible ready-signal
- · Power-on and ready-to-use lights

In the easiest way

- ${\boldsymbol{\cdot}}$ Easy cleaning thanks to removable, dishwasher-safe plates
- · Vertical, compact storage

Highlights

Large plates

Fits all kinds of sandwiches thanks to the large plates.

Digital timer

Digital timer with audible ready-signal.

Removable, dishwasher-safe plates

Easy cleaning thanks to removable, dishwasher-safe plates.

Vertical, compact storage

Vertical, compact storage.

Specifications

General specifications

Non-stick coated plates Cool-touch handle Cord storage Anti-slip feet

Technical specifications

Cord length: 0.9 m

Design specifications

Color(s): white/yellow Materials: Phenolic housing

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-07 Version: 1.0.1

12 NC: 0000 000 00000

www.philips.com

