PHILIPS

Steam iron

EasySpeed

Steam 30g/min;100g steam boost

Non-stick soleplate

Anti-calc

2100 Watts

GC2040/70



Fast, from start to finish

3 ways to speed up your ironing

This EasySpeed iron speeds up your ironing thanks to: triple precision tip, even heat distribution across the soleplate and continuous steam.

Easily removes creases

- Power up to 2100 W enabling constant high steam output
- 100 g steam boost to remove stubborn creases easily
- Continuous steam up to 30 g/min for better crease removal
- Non-stick soleplate coating
- Vertical steam for crease removal in hanging fabrics

Longer lifetime

Calc clean slider to easily remove scale out of your iron

Comfortable ironing

- Drip-stop system keeps your garments spotless while ironing
- Triple precision tip for optimal control and visibility
- Even steam distribution for efficient ironing
- A fine spray evenly moistens the fabric

Highlights

Power up to 2100 W



Power up to 2100 W enables constant high steam output.

Steam boost up to 100 g



Steam boost up to 100g for fast removal of even the most stubborn creases.

Up to 30 g/min of steam



Continuous steam up to 30 g/min for better crease removal.

Non-stick soleplate



The soleplate of your Philips iron is coated with a special non-stick layer for good gliding performance on all fabrics.

Vertical steam



This Philips iron has a vertical steam function, for crease removal in hanging fabrics.

Calc clean slider



This steam iron can be operated with normal tap water and the calc clean slider makes it easy to remove any built-up scale out of your iron. To maintain the performance of your Philips steam iron, you should use this scale clean function once a month when using normal tap water.

Drip stop system



Drip Stop system lets you iron delicate fabrics at low temperatures without having to worry about stains from water droplets.

Triple precision tip



The tip of this Philips iron is precise in 3 ways: it has a pointed tip, button groove and a sleek design of the nose. Triple Precision tip enables you to reach even into the most tricky areas, e.g. around the buttons or between the pleats.

Even steam distribution

Thanks to the carefully crafted soleplate design, the steam is distributed evenly across the soleplate. This way you need less strokes to evenly moisten the garment and therefore less time to complete the ironing.

Spray



The spray function produces a fine mist that evenly moistens the fabric, making it easier to iron out creases.

GC2040/70

Specifications

Fast & powerful crease removal

Soleplate: Non-stick Steam output Continuous steam output: 30 g/min Steam boost: 100 g Vertical steaming Spray Power: 2100 W Easy to use Water tank capacity: 270 ml Drip stop Reaching tricky areas: Triple precision tip

Calc management Calc clean solution: Self clean

© 2019 Koninklijke Philips N.V. All Rights reserved.

their respective owners.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or

Issue date 2019-02-12 Version: 4.0.1

EAN: 08 71010 36455 42

www.philips.com

