

Pluto Non DI_Taiwan

90x127mm

Control




Mode switch/
Filter reset


• Auto • Turbo • Sleep



Power on/off



Display



Air quality ring



Air quality

Good Fair Poor Very poor

Filter replacement alert

Maintenance

Clean the surface of the filter

Replace filter when display shows



- Clean the surface of the filter every 4 weeks.



- Long press the for 3 seconds after replacing the filter (FY0194).

The filter may produce smell after being used for a while because of the absorption of indoor air. Remove the filter and place it where it has direct sunlight and ventilation for several hours. Re-install and try using it again. If the odor remains, please replace the filter.

3000 xxx xxxxxx