


# PHILIPS

Sneaker Cleaner

3x brushhead

CP6831



## Sponge Brush

The sponge brush is ideal for use on delicate materials like PVC, leather, suede and smooth rubber.

### Easy cleaning

- Simple to use in three steps

### Effective cleaning

- The rotating brush cleans effectively

### Safe for your sneakers

- Sponge brush for delicate surfaces

# Highlights

## Effective cleaning



With up to 500 rotations per minute the Philips Sneaker Cleaner delivers an effective clean.

## Sponge brush



The sponge brush is ideal to use for delicate materials like PVC, leather, suede and smooth rubber.

## Simple to use



Simply wet the brush with water and soap, switch on the Philips Sneaker Cleaner and wipe the sneaker with a clean towel when done.

# Specifications

## Safe for your sneakers

3 Brushes included: Sponge

