


PHILIPS

Potato masher
paddle

CP1387



to replace your current Potato masher paddle

this is the replacment part for your Potato masher Accessory

Ease of using Philips spare parts

- Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Replaceable part

For kitchen appliance model:: HR253x, HR254x

