

Philips Toaster oven

HD4493/08

Delicious hot food easily

30-minute timer

A toaster oven designed to help you make delicious food and snacks every time. Toasts and warms, and has a lot of features that make it easy to get good food. Includes 30-minute timer, crumb tray and baking tray.

Safe to use

• On/off light

Easy to experience

- Large square baking tray (230 x 230 mm)
- Detachable grid
- Ready bell sounds when food is ready
- · Removable crumb tray for easy cleaning

Delicious food

- 30-minute timer shuts off the oven once ready
- Toasts or warms food and snacks



Specifications

Technical specifications

- Power: 900 W
- · Cord length: 1.0 m
- Capacity: 9 L
 Voltage: 220-240 V
- Frequency: 50-60 Hz
- Heating elements: Quartz (2x)
- Effective capacity: 5.7 L

General specifications

• Non slip feet

Accessories included

• Baking tray: $230 \times 230 \text{ mm}$

Design specifications

- Materials: Metal housing, plastic knobs/handles
- Available color(s): Pearl white/grey/blue /08

Highlights

Function

Toasts or warms food and snacks.

30-minute timer



30-minute timer shuts off the oven once ready.

Baking tray



Large square baking tray (230 x 230 mm)

Removable crumb tray



Is easy to clean thanks to its removable crumb tray.

On/off light On/off light

Ready bell Ready bell sounds when food is ready.

Detachable grid Detachable grid



Issue date 2021-12-18

Version: 1.1.1

© 2021 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com