Philips Premium Compact Grey ON/OFF Knob for Airfryer



Grey

CP0356

Replace your current on/off knob

This knob is needed for turning your Airfryer on and off.

Ease of using Philips spare parts

• Easily renew your product with original Philips parts



Grey ON/OFF Knob for Airfryer Grey

Specifications

Replaceable part • Fits product family: HD972x/xx, HD962x CP0356/01

Highlights

Easy replacement of product parts From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

