



## Sensiflex replacement brushes

### Sonicare toothbrush replacement head

Sensiflex replacement brushes. Replace the brush head of your Philips Sonicare electric toothbrush every 6 months for optimal performance.

### **Double Cleaning Action**

- · Naturally whiter teeth
- · Cleans visible teeth surfaces

#### Gentle on gums, tough on plaque

· Gum Protection system

### Highlights

### **Gum Protection system**



Philips Sonicare's patented Gum Protection system adjusts to maintain optimal brushing pressure

### **Double Cleaning Action**



Cleans visible teeth surfaces while the active tip targets hard-to-reach plaque in between teeth.

#### **Naturally whiter teeth**



Naturally whiter teeth

# Specifications

Cleaning performance
Brush heads: 4

© 2022 Koninklijke Philips N.V. All Rights reserved.

