

Philips Toaster oven

HD4493/08

# Delicious hot food easily

### 30-minute timer

A toaster oven designed to help you make delicious food and snacks every time. Toasts and warms, and has a lot of features that make it easy to get good food. Includes 30-minute timer, crumb tray and baking tray.

#### Safe to use

• On/off light

#### Easy to experience

- Large square baking tray (230 x 230 mm)
- Detachable grid
- · Ready bell sounds when food is ready
- · Removable crumb tray for easy cleaning

### **Delicious food**

- 30-minute timer shuts off the oven once ready
- Toasts or warms food and snacks



## **Specifications**

#### **Technical specifications**

- Cord length: 1.0 m
   Voltage: 220-240 V • Power: 900 W
- Capacity: 9 L
- Frequency: 50-60 Hz
- Heating elements: Quartz (2x)
- Effective capacity: 5.7 L

#### **General specifications**

Non slip feet

#### **Accessories included**

• Baking tray:  $230 \times 230 \text{ mm}$ 

### **Design specifications**

- Materials: Metal housing, plastic knobs/handles
- Available color(s): Pearl white/grey/blue /08

## Highlights

#### **Function**

Toasts or warms food and snacks.

#### 30-minute timer

30-minute timer shuts off the oven once ready.

Large square baking tray (230 x 230 mm)

Removable crumb tray
Is easy to clean thanks to its removable crumb tray.

### On/off light

On/off light

#### Ready bell

Ready bell sounds when food is ready.

## **Detachable grid** Detachable grid



Issue date 2022-03-29

Version: 1.1.1

© 2022 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com