

PHILIPS


VisaPure

ADVANCED

FRESH EYES



www.philips.com

 >75% recycled paper

4222.100.5485.1 (11/15)

Introduction

The Fresh Eyes head with its customized DualMotion program gently massages the skin below the eye. The premium coating gives a cooling and refreshing experience: a boost of freshness for tired eyes in only 30 seconds!

Note: Please read all instructions for VisaPure Advanced before using the Fresh Eyes head.

Important

Caution

- The Fresh Eyes head is intended for use on the bony area below the eye. Do not place the Fresh Eyes head on the eyeball or on the eyelid.
- Do not use the Fresh Eyes head if it is damaged or broken to avoid injuries.
- Do not use the Fresh Eyes head if you have glaucoma, an eye injury, or have had eye surgery within the last 12 months.
- Do not use the Fresh Eyes head if you have an allergy to aluminium.
- If you wear contact lenses or glasses, remove them when you use the Fresh Eyes head.
- Do not put the Fresh Eyes head in the freezer, as this may cause a hazardous situation for your skin.
- Do not put the Fresh Eyes head in the dishwasher.

Fresh eyes

The Fresh Eyes head is suitable for all skin types. We advise you to use it once a day in the morning.

The 30 seconds fresh eyes program

It consists of 2 treatment periods of 15 seconds.

It has 2 intensity settings: intensity setting 1 vibrates, intensity setting 2 vibrates and rotates.

Note: The rotation direction is optimized for the skin zone treated.

Start below your right eye.

When the appliance pauses after 15 seconds, move to the area below your left eye.

Using the Fresh Eyes head

You can use the Fresh Eyes head on dry skin or after applying cream to your skin.

- 1 Push the Fresh Eyes head onto the connection pin until it locks into position with a click (Fig. 1).
- 2 Press the on/off button to switch on the appliance and choose your preferred setting.

Note: When you attach a different head the appliance recognizes it. You hear a beep and the intensity setting indications flash alternately. (Fig. 2)

- 3 Place the Fresh Eyes Head on the bony area below the right eye. Gently move the head from the nose towards the temple and repeat this movement (Fig. 3).

Do not push the head too hard onto the skin to make sure the treatment remains comfortable.

- 4 After 15 seconds, the appliance pauses briefly to let you know that you have to move it to the area below the left eye (Fig. 4).
- 5 When the program is finished, clean the Fresh Eyes Head with water and mild soap.

Fresh Eyes head replacement

We advise you to replace the Fresh Eyes Head after one year, or earlier if it is damaged. Replacement Fresh Eyes heads are available from www.shop.philips.com or from the shop where you purchased your Philips VisaPure Advanced.

Úvod

Nástavec Svieže oči s prispôsobeným programom DualMotion jemne masíruje pokožku pod okom. Prémiový povrch poskytuje chladiaci a osviežujúci pocit: lepší pocit sviežosti pre unavené oči len za 30 sekúnd!

Poznámka: Pred použitím nástavca Svieže oči si prečítajte všetky pokyny pre kefku VisaPure Advanced.

Dôležité

Výstraha

- Nástavec Svieže oči je určený na použitie na kostnatej oblasti pod okom. Nástavec Svieže oči neumiestňujte na očné bulvu ani na viečko.
- Nástavec Svieže oči nepoužívajte, ak je poškodený alebo zlomený, aby nedošlo k poraneniám.
- Nástavec Svieže oči nepoužívajte, ak máte glaukóm, poranené oko alebo ak ste za posledných 12 mesiacov absolvovali operáciu očí.
- Nástavec Svieže oči nepoužívajte, ak máte alergiu na hliník.
- Ak nosíte kontaktné šošovky alebo okuliare, pred použitím nástavca Svieže oči si ich vyberte, resp. zložte.
- Nástavec Svieže oči nekladajte do mrazničky, pretože to môže viesť k nebezpečenstvu pre vašu pokožku.
- Nástavec Svieže oči nekladajte do umývačky riadu.

Svieže oči

Nástavec Svieže oči je vhodný pre všetky typy pokožky. Odporúčame vám, aby ste ho používali raz denne ráno.

30-sekundový program Svieže oči

Skladá sa z dvoch fáz ošetrovania po 15 sekúnd.

Má dve nastavenia intenzity: nastavenie intenzity 1 vibruje, nastavenie intenzity 2 vibruje a otáča sa.

Poznámka: Smer otáčania je optimalizovaný pre ošetrovanú zónu pokožky.

Začnite pod pravým okom. Keď zariadenie po 15 sekundách zastane, presuňte ho na oblasť pod ľavým okom.

Používanie nástavca

Svieže oči

Nástavec Svieže oči používajte na suchej pokožke alebo po aplikovaní krému na pokožku.

- 1 Nástavec Svieže oči zatlačte na prípojný kolík, až kým sa s cvaknutím (Obr. 1) nezaistí v správnej polohe.
- 2 Stlačením vypínača zapnete zariadenie a vyberte si uprednostňované nastavenie.

Poznámka: Keď pripojíte iný nástavec, zariadenie ho rozpozná. Budete počuť pípnutie a indikátory nastavenia intenzity budú striedavo (Obr. 2) blikať.

- 3 Nástavec Svieže oči umiestnite na kostnatú oblasť pod pravým okom. Nástavcom jemne pohybujte od nosa k spánku a tento pohyb (Obr. 3) opakujte

Nezatlačajte nástavec na pokožku veľmi silno, aby bolo ošetrovanie príjemné.

- 4 Po 15 sekundách zariadenie na chvíľu zastane, čím signalizuje, že ho máte presunúť na oblasť pod ľavým okom (Obr. 4).
- 5 Po dokončení programu vyčistíte nástavec Svieže oči vodou a jemným mydlom.

Výmena nástavca

Svieže oči

Nástavec Svieže oči odporúčame vymeniť po jednom roku, prípadne skôr, ak je poškodený.

Náhradné nástavce Svieže oči sú k dispozícii na našej webovej lokalite www.shop.philips.com alebo v predajni, v ktorej ste zakúpili kefku VisaPure Advanced od spoločnosti Philips.