

说明

面部焕活按摩附件与日式按摩专家合作设计。定制的双重振旋科技程序可轻柔地刺激皮肤，促进血液流动，放松肌肉。促进血液循环，可为肌肤提供更多氧气和营养，让您的肌肤容光焕发、生机盎然，尽显健康光泽！

注意：使用面部焕活按摩附件之前，请先阅读 VisaPure Men Advanced 的所有说明。

注意事项

警告

- 面部焕活按摩附件只能用于按摩脸颊。
- 如果面部焕活按摩附件出现损坏或毁坏，请勿再使用，以免造成人体伤害。
- 请勿将面部焕活按摩附件放入洗碗机中。

提拉按摩

面部焕活按摩附件适合各种皮肤类型。建议每周使用 2-3 次。在按摩肌肤之前，建议您先用 VisaPure Men Advanced 洁面刷清洁面部。

3 分钟提拉按摩程序

它包含 2 段各 1 分半钟的护理期。面部焕活按摩附件只能用于护理左右脸颊。面颊区域包括下巴、鼻子和上唇之间的部位以及眼睛和耳朵之间的部位。

注意：每段护理期可提供专为护理皮肤而优化的特定旋转方向。

请勿在眼睛周围的敏感部位使用面部焕活按摩附件。

使用面部焕活按摩附件

您可以在干燥的皮肤上使用面部焕活按摩附件，或在皮肤上涂抹乳液或精油后使用。

- 1 将面部焕活按摩附件推入连接端子，直至其锁定到位（可听到“咔哒”（图 1）一声）。
- 2 按开/关按钮启动产品，并选择所需设置。

注意：安装不同的刷头时，产品会自动识别刷头。您会听到一声哔声，并且强度设置指示灯会交替（图 2）闪烁。

- 3 将面部焕活按摩附件置于右颊。在鼻子至耳朵的皮肤上轻轻地移动（图 3）刷头，重复这一动作。请勿太过用力地将刷头压在皮肤上，以确保舒适护理
- 4 1 分半钟后，产品会暂停片刻，提示您须将其移至另一边脸颊（图 4）。
- 5 程序结束后，请用水和中性肥皂清洁面部焕活按摩附件。

面部焕活按摩附件更换

建议您在使用一年后更换面部焕活按摩附件；如果附件损坏，则应提前更换。替换刷头可从 www.shop.philips.com 或您购买飞利浦 VisaPure Men Advanced 的商店购得。



PHILIPS



PHILIPS

飞利浦面部充电按摩附件 MS606
产地：波黑
生产日期：请见产品包装
检验：合格

经销单位：飞利浦（中国）投资有限公司
上海市天目西路218号1602-1605
全国顾客服务热线：4008 800 008

适用型号详见产品包装

保留备用

发行日期：21/07/2017



75% recycled paper
75% 再生纸

www.philips.com

42221007406.2 (07/17)

ENGLISH

Introduction

Introduction

The Revitalising Massage head is designed together with experts in Japanese massage. The customised DualMotion program gently stimulates the skin to encourage the blood flow and relax the muscles. By encouraging the blood flow, more oxygen and nutrients are available in the skin, making your skin look radiant, revitalised and giving it a healthy glow!

Note: Please read all instructions for VisaPure Men Advanced before using the Revitalising Massage head.

Important

Caution

- The Revitalising Massage head is intended to massage the cheeks.
- Do not use the Revitalised Massage head if it is damaged or broken to avoid injuries.
- Do not put the Revitalised Massage head in the dishwasher.

Revitalising Massage

The Revitalising Massage head is suitable for all skin types. We advise you to use it 2-3 times a week. Before you massage the skin, we advise you to first cleanse your face with VisaPure Men Advanced.

The 3 minutes Revitalising massage program

It consists of 2 treatment periods of 1 1/2 minute. The Revitalising Massage head is intended to treat the right and left cheek. The cheek zones include the chin, the area between the nose and upper lip and the areas between the eyes and ears.

Note: Each treatment period has a specific rotation direction optimised for the skin zone treated.

Do not use the Revitalising Massage head on the sensitive area around the eyes.

Using the Revitalising Massage head

You can use the Revitalising Massage head on dry skin or after applying cream or oil to your skin.

- 1 Push the Revitalising Massage head onto the connection pin until it locks into position with a click (Fig. 1).
- 2 Press the on/off button to switch on the appliance and choose your preferred setting.

Note: When you attach a different head the appliance recognises it. You hear a beep and the intensity setting indications flash alternately (Fig. 2).

- 3 Place the Revitalising Massage head on your right cheek. Gently move the head across your skin, from the nose towards the ear and repeat this movement (Fig. 3). Do not push the head too hard onto the skin to make sure the treatment remains comfortable.
- 4 After 1 1/2 minute, the appliance pauses briefly to let you know that you have to move it to the other cheek (Fig. 4).
- 5 When the program is finished, clean the Revitalising Massage head with water and mild soap.

Revitalising Massage Head replacement

We advise you to replace the Revitalising Massage Head after 1 year, or earlier if it is damaged. Replacement heads are available from www.shop.philips.com or from the shop where you purchased your Philips VisaPure Men Advanced.

繁體中文

簡介

活力滾輪按摩頭是與日式按摩專家一同設計而成。自訂式 DualMotion 設定可溫和地刺激肌膚，促進血液循環，放鬆肌肉。促進血液循環後，肌膚會獲得更多氧氣和營養，讓您的肌膚煥發光采，重獲活力，散發出健康的光澤！

注意： 使用活力滾輪按摩頭之前，請先詳閱 VisaPure Men Advanced 的使用說明。

重要事項

警告

- 活力滾輪按摩頭專為按摩臉頰使用。
- 如果活力滾輪按摩頭損壞，則請勿使用，以免受傷。
- 請勿將活力滾輪按摩頭放入洗碗機清洗。

活力滾輪按摩

活力滾輪按摩頭適用於所有膚質。我們建議您每週使用 2 - 3 次。在開始按摩肌膚前，建議您先以 VisaPure Men Advanced 清潔臉部。

3 分鐘活力滾輪按摩設定

其包含 2 組療程，每組療程時間為 1 分半鐘。活力滾輪按摩頭專為左右臉頰使用。頰部位包括下巴、鼻子與上唇間的區域，以及眼睛與耳朵間的區域。

注意： 每個療程階段有其特定旋轉方向，好為肌膚使用部位帶來最佳效果。

請勿將活力滾輪按摩頭用於眼睛周圍的敏感區域。

使用活力滾輪按摩頭

活力滾輪按摩頭可用於乾燥皮膚或已塗抹乳霜或護膚油的皮膚。

- 1 將活力滾輪按摩頭推入連接插座，直到聽到「喀噠」(圖 1)一聲完全卡入定位為止。
- 2 按下開關按鈕以開啟產品電源，選擇您偏好的設定。

注意： 安裝不同的刷頭時，產品便會辨識刷頭。您將聽到嗶聲，強度設定指示燈會交互(圖 2)閃爍。

- 3 將活力滾輪按摩頭放在右臉頰上。輕輕在皮膚表面移動刷頭，從鼻子往耳朵移動，並重複此動作(圖 3)。為確保使用過程舒適，請勿將按摩頭用力壓於皮膚上。
- 4 1 分半鐘後，本產品會短暫停頓，讓您知道您必須將產品移到另一邊臉頰(圖 4)。
- 5 療程結束之後，請使用清水與軟性肥皂清潔活力滾輪按摩頭。

更換活力滾輪按摩頭

建議您於使用 1 年後更換活力滾輪按摩頭，若有損壞請提前更換。您可以在 www.shop.philips.com 或當初購買飛利浦 VisaPure Men Advanced 的商店購買替換刷頭。