


HP6512



PHILIPS



Introduction

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

With your new epilator you can remove unwanted hair quickly, easily and effectively. The rotating discs catch even the shortest hairs (down to 0.5mm) and pull them out by the root. The hairs that grow back are soft and thin. The ideal combination of epilator, exfoliation glove and cooling glove makes epilation more comfortable and leaves your skin smooth, fresh and hair-free for several weeks.

General description (Fig. 1)

- A** Hair-lifting attachment with massage element
- B** Shaving head comb attachment
- C** Shaving head protection cap
- D** Shaving head
- E** Epilating discs
- F** Epilating head
- G** On/off slide
 - O = off
 - I = normal speed
 - II = high speed (only to be used for epilating head)
- H** Socket for small plug
- I** Exfoliation glove
- J** Ice gel pad
- K** Cooling glove
- L** Small plug
- M** Adapter
- N** Cleaning brush
- O** Storage pouch (not shown)

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Keep the appliance and the adapter dry.
- Do not use the appliance near or over a washbasin or bath filled with water (Fig. 2).
- Do not use the appliance in the bath or in the shower (Fig. 3).
- If you use the appliance in the bathroom, do not use an extension cord (Fig. 4).

Warning

- Only use the appliance in combination with the adapter supplied.
- Do not use the appliance or the adapter if it is damaged.
- If the adapter is damaged, always have it replaced with one of the original type in order to avoid a hazard.
- The adapter contains a transformer. Do not cut off the adapter to replace it with another plug, as this causes a hazardous situation.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Caution

- This appliance is only intended for removing women's body hair on areas below the neck: underarms, bikini area and legs. Do not use it for any other purpose.
- To prevent damage and injuries, keep the **running** appliance (with or without attachment) away from scalp hair, eyebrows, eyelashes, clothes, threads, cords, brushes etc.
- Do not use the appliance on irritated skin or skin with varicose veins, rashes, spots, moles (with hairs) or wounds without consulting your doctor first. People with a reduced immune response or people who suffer from diabetes mellitus, haemophilia or immunodeficiency should also consult their doctor first.
- Your skin may become a little red and irritated the first few times you use the epilator. This phenomenon is absolutely normal and quickly disappears. As you use the appliance more often, your skin gets used to epilation, skin irritation decreases and regrowth becomes thinner and softer. If the irritation

has not disappeared within three days, we advise you to consult a doctor.

- Do not use the epilating head, the shaving head, the hair-lifting attachment or the shaving comb if it is damaged or broken, as this may cause injury.

Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

Epilation tips

- When you use the appliance for the first time, we advise you to try it out on an area with only light hair growth to get accustomed to the epilation process.
- Epilation is easier just after taking a bath or shower. Make sure your skin is completely dry when you start epilating.
- Make sure your skin is clean, entirely dry and free from grease. Do not use any cream before you start epilating.
- Epilation is easier and more comfortable when the hair has the optimum length of 3–4 mm. If the hairs are longer, we recommend that you either shave first and epilate the shorter regrowing hairs after 1 or 2 weeks or that you use the shaving head with the shaving head comb attachment to pretrim hairs to this ideal length.
- When you epilate for the first time, we advise you to epilate in the evening, so that any reddening that develops can disappear overnight.
- While epilating stretch your skin with your free hand. This lifts up the hairs and helps to minimise the pulling sensation.
- For optimal performance, place the appliance on the skin at right angles (90°) with the on/off slide pointing in the direction in which you are going to move the appliance. Guide the appliance across the skin against the direction of hair growth in a slow, continuous movement without exerting any pressure.
- On some areas, hair may grow in different directions. In this case, it may be helpful to move the appliance in different directions to achieve optimal results.
- When you use the hair-lifting attachment with massage element, make sure that the massage element and the comb of the hair-lifting attachment always stay in contact with the skin.

Preparing for use

Freezing the ice gel pad

Keep the ice gel pad out of the reach of children (Fig. 5).

Do not use a damaged ice gel pad (Fig. 6).

Do not use the ice gel pad if you are hypersensitive to cold.

- 1** Put the ice gel pad without the cooling glove in the freezer or freezing compartment (***) at least 2 hours before you start to epilate (Fig. 7).

Make sure the outside of the ice gel pad is completely dry before you freeze it.

Tip: You can store the ice gel pad in the freezer permanently.

Using the appliance

Note: Clean the epilating head before first use.

Connecting the appliance

- 1** Insert the small plug into the appliance (Fig. 8).
- 2** Insert the adapter into the wall socket.

Epilating the legs with the cooling glove

Use the cooling glove immediately after epilation to soothe and relax your skin.

- 1** Thoroughly clean the area to be epilated. Remove any residues of oil, cream etc. Then dab the area dry.
- 2** Put the ice gel pad in the compartment of the cooling glove and close the Velcro fastener (Fig. 9). Only use the ice gel pad in combination with the cooling glove.
- 3** Select the desired speed to switch on the appliance (Fig. 10).

Preferably use speed II. Switch to speed I for areas with little hair growth, for hard-to-reach areas and for areas where bones are located directly beneath the skin, such as knees and ankles.

- 4** For optimal results, place the epilator at a 90° angle onto the skin with the on/off slide pointing in the direction in which you are going to move the appliance. Stretch your skin with your free hand (Fig. 11).

- 5** After you have epilated a certain area or after each stroke with the epilator, push your hand into the cooling glove and start cooling the area (Fig. 12).

Do not leave the cooling glove on the same area for more than 2 minutes.

Epilating with the hair-lifting attachment with massage element

Use the hair-lifting attachment with massage element when you are new to epilation. This attachment ensures optimal hair lifting, relaxes the skin and minimises the pulling sensation of epilation.

Note: You get the best results and epilating is most comfortable when the hairs are not too long (3–4mm). If the hairs are longer, trim them to this length with the shaving head with comb attachment (see section 'Pretrimming with the shaving head and comb attachment before epilation' in this chapter).

- 1** Thoroughly clean the area to be epilated. Remove any residues of oil, cream etc. Then dab the skin dry.
- 2** Put the hair-lifting attachment with massage element on the epilating head (Fig. 13).
- 3** Follow steps 3 to 6 in the section 'Epilating with the cooling glove' above.

Shaving the underarms and bikini line

Use the shaving head to shave sensitive areas such as the bikini line.

Note: The shaving head can only be used at speed setting I.

- 1** Push the epilating head in the direction of the arrows on the back of the appliance (1) and remove it from the appliance (2) (Fig. 14).
- 2** Put the shaving head on the appliance (1) and push it against the direction of the arrows on the back of the appliance (2) to fix it. (Fig. 15)
- 3** Switch on the appliance. (Fig. 16)

Note: Speed II does not work when the shaving head is attached.

- 4** Stretch the skin with your free hand. When shaving the underarms, raise your arm to stretch the skin.
- 5** Place the appliance at a 90° angle onto your skin, with the on/off slide pointing in the direction in which you are going to move the appliance.
- 6** Move the appliance against the direction of hair growth. (Fig. 17)

Note: Make sure that the shaving foil with integrated trimmer is always fully in contact with the skin.

- Shave your bikini line as shown in the figure. (Fig. 18)
- Shave your underarms as shown in the figure. Move the appliance in different directions. (Fig. 19)

- 7** When you have finished shaving, switch off the appliance and clean the shaving head (see chapter 'Cleaning and maintenance').
- 8** Put the protection cap on the shaving head when you store the appliance.

Pretrimming with the shaving head and comb attachment before epilation

Use the shaving head and comb attachment to trim your bikini line to a hair length of 4mm. You can also use the trimming comb to pretrim long hairs (longer than 10mm).

Note: The shaving head can only be used at speed setting I.

- 1** Push the epilating head in the direction of the arrows on the back of the appliance (1) and remove it from the appliance (2) (Fig. 14).

2 Put the shaving head on the appliance (1) and push it against the direction of the arrows on the back of the appliance (2) to fix it (Fig. 15).

3 Put the comb on the shaving head (Fig. 20).

4 Follow steps 3 to 6 in section 'Shaving the underarms and bikini line'. To obtain an even result, make sure that the comb attachment stays fully in contact with the skin.

Note: Do not place the appliance on the skin too steeply.

5 When you have finished pretrimming, switch off the appliance and clean the shaving head (see chapter 'Cleaning and maintenance').

6 Put the protection cap on the shaving head when you store the appliance.

Using the exfoliation glove

Use the exfoliation glove in the shower once or twice a week to prevent ingrown hairs and to get a fresh and smooth skin. Make circular movements with the exfoliation glove from your ankle to your knee.

Note: Do not use the exfoliation glove within 24 hours before or after epilation.

Cleaning and maintenance

Note: Make sure the appliance is switched off and unplugged before you start to clean it.

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

- Never rinse the appliance or the adapter under the tap (Fig. 21).
- Keep the appliance and the adapter dry (Fig. 22).

Cleaning the cooling glove

- 1** Remove the ice gel pad from the cooling glove.
- 2** Clean the cooling glove with a moist cloth after each use.

Note: Make sure the outside of the ice gel pad is completely dry before you freeze it again.

Cleaning the attachments

- 1** Remove the attachment.
 - Remove the hair-lifting attachment with massage element from the epilating head (Fig. 23).
 - Remove the shaving head comb attachment by pulling it off the shaving head (Fig. 24).
- 2** Remove loose hairs from the attachment.
- 3** Rinse the attachment under the tap while turning it.
- 4** Dry the attachment before you use or store it.

Cleaning the epilating head

- 1** Push the epilating head in the direction of the arrows on the back of the appliance (1) and remove it (2) (Fig. 14).
- 2** Remove loose hairs with the cleaning brush (Fig. 25).
- 3** Rinse the epilating head under the tap for 5-10 seconds while turning it (Fig. 26).
- 4** Shake the epilating head firmly (Fig. 27).
Dry the epilating head thoroughly with a tea towel.

Note: Make sure the epilating head is completely dry before you place it back onto the appliance.

Cleaning the shaving head

- 1** Push the shaving head in the direction of the arrows on the back of the appliance (1) and remove it (2). (Fig. 28)
- 2** Remove the shaving foil from the shaving head (Fig. 29).
- 3** Rinse the shaving foil and the inside of the shaving head under the tap for 5-10 seconds while turning them (Fig. 30).
- 4** Shake the shaving foil and shaving head firmly (Fig. 31).

Note: Do not exert any pressure on the shaving foil to avoid damage.

Note: Make sure the shaving foil and shaving head are completely dry before you place it back onto the appliance.

5 Put the protection cap on the shaving head.

Tip: Rub a drop of sewing machine oil onto the shaving foil twice a year.

Storage

- Store the epilator, the attachments and the adapter in the storage pouch.
- Put the protection cap on the shaving head when you store the appliance.

Replacement

All parts of the appliance can be replaced. If you need to replace one or more of the parts, go to your Philips dealer or an authorised Philips service centre.

Shaving head

If you use the shaving head two or more times a week, replace the shaving unit after one or two years or if it is damaged.

Environment

- Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment (Fig. 32).
- If the ice gel pad is damaged, you can throw it away with the normal household waste.

Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at **www.**

philips.com or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Guarantee restrictions

The shaving head is not covered by the terms of the international guarantee because it is subject to wear.

한국어

소개

필립스 제품을 구입해 주셔서 감사합니다!
필립스가 드리는 지원 혜택을 받으실 수 있도록 www.philips.co.kr에서 제품을 등록하십시오.
새롭게 선보인 제모기는 체모를 한결 빠르고 효과적이며 손쉽게 제거합니다. 회전식 디스크가 아무리 짧은 체모(최소 0.5mm까지)라도 모근까지 완벽하게 제거해 줍니다. 새로 나는 체모는 부드럽고 가늘게 자라납니다. 제모기, 각질 제거 장갑 및 쿨링 장갑의 이상적인 조합으로 편하게 제모하며 몇 주 동안 피부가 부드럽고 매끄럽게 유지될 수 있습니다.

각 부의 명칭 (그림 1)

- A** 마사지 부품이 장착된 헤어 리프트 액세서리
- B** 셰이빙 헤드 빗 액세서리
- C** 셰이빙 헤드 보호 캡
- D** 셰이빙 헤드
- E** 제모 디스크
- F** 제모 헤드
- G** 전원 스위치
 - O = 꺼짐
 - I = 일반 속도
 - II = 고속(제모 헤드에만 사용)
- H** 소형 플러그 콘센트
- I** 각질 제거 장갑
- J** 아이스 젤 패드
- K** 쿨링 장갑
- L** 소형 플러그
- M** 어댑터
- N** 세척용 브러시
- O** 보관용 파우치(그림 없음)

중요 사항

본 제품을 사용하기 전에 이 사용 설명서를 주의 깊게 읽고 나중에 참조할 수 있도록 잘 보관하십시오.

위험

- 제품과 어댑터에 물이 묻지 않도록 주의하십시오.
- 본 제품을 물이 채워진 세면대나 욕조 위 등 물이 있는 근처에서 사용하지 마십시오 (그림 2).
- 본 제품을 목욕이나 샤워 중에 사용하지 마십시오 (그림 3).
- 욕실에서 사용할 경우 연장선을 사용하지 마십시오 (그림 4).

경고

- 함께 제공된 어댑터만 사용하십시오.
- 제품이나 어댑터가 손상되면 사용하지 마십시오.
- 어댑터에 손상 부위가 있으면, 위험할 수 있으므로 반드시 정품으로 교체하여 사용하십시오.
- 어댑터에는 변압기가 내장되어 있습니다. 위험할 수 있으므로 어댑터를 제거하고 다른 플러그로 교체하지 마십시오.
- 신체적인 감각 및 정신적인 능력이 떨어지거나 경험과 지식이 풍부하지 않은 성인 및 어린이는 혼자 제품을 사용하지 말고 제품 사용과 관련하여 안전에 책임 질 수 있도록 지시사항을 충분히 숙지한 사람의 도움을 받으십시오.
- 어린이가 제품을 가지고 놀지 못하도록 지도해 주십시오.

주의

- 이 제품은 목 아래 부위(거드랑이, 비키니 라인 부위 및 다리)에 있는 여성의 체모를 제거하는 용도로만 사용됩니다. 다른 용도로 이 제품을 사용하지 마십시오.
- 제품이 손상되거나 다칠 수 있으므로, 액세서리

연결 여부와 관계없이 제품 사용 도중 모발, 눈썹, 속눈썹, 옷, 실, 전깃줄, 빗 등에 닿지 않도록 주의하십시오.

- 민감성 피부나 정맥류, 발진, 뾰루지가 있는 피부, 털이 있는 점, 사마귀나 상처 부위 등에 제품을 사용하려면 먼저 의사와 상담하십시오. 면역 반응이 저하되거나 당뇨병, 혈우병, 면역 결핍증을 앓고 있는 경우 의사와 상담 후 사용하십시오.
- 처음 몇 차례는 피부가 조금 빨개지거나 자극을 느낄 수 있습니다. 하지만 흔히 나타나는 현상이며 곧 사라집니다. 제모기 사용 횟수가 늘어나면서 익숙해지면, 피부 자극은 줄어들고 전보다 가늘고 부드러운 체모가

새로 자라납니다. 3일이 지나도 피부 자극이 사라지지 않으면 의사와 상담하십시오.
- 제모 헤드, 셰이빙 헤드, 헤어 리프트 액세서리 또는 면도용 빗이 손상되었거나 고장 난 경우, 다칠 수 있으므로 사용하지 마십시오.

EMF(전자기장)

이 필립스 제품은 EMF(전자기장)와 관련된 모든 기준을 준수합니다. 이 사용 설명서의 지침에 따라 적절하게 취급할 경우 이 제품은 안전하게 사용할 수 있으며 이는 현재까지의 과학적 증거에 근거하고 있습니다.

제모 팁

- 제품을 처음 사용하는 경우에는 익숙해질 때까지 체모가 가는 부위부터 사용해보십시오.
- 목욕이나 샤워 직후에 하면 제모가 한결 쉬워집니다. 전신이 마른 상태에서 제모를 시작하십시오.
- 피부가 깨끗하고 물기나 유분이 없어야 합니다. 크림을 바르지 말고 체모를 제거하십시오.
- 체모의 길이가 3-4mm일 때가 제모하기에 가장 쉽고 효과적입니다. 체모가 이보다 더 길면 먼저 면도한 다음 1-2주 후에 짧게 자라난 체모를 제모하거나, 빗 액세서리가 장착된 셰이빙 헤드를 사용하여 적절한 길이로 체모를 미리 잘라주는 것이 좋습니다.
- 제모기를 처음 사용하는 경우에는 피부가 붉어지는 증상이 나타나도 밤사이에 사라질 수 있도록 저녁에 제모하는 것이 좋습니다.
- 제모를 할 때 다른 한 손으로 피부를 잡아당겨 체모를 들어올리고 제모로 인한 자극을 최소화하십시오.
- 최적의 성능을 위해서는 전원 스위치가 제모기를 움직일 방향을 향하게 한 상태에서 제모기를 피부와 수직(90°)이 되게 세우십시오. 제모기에 압력을 가하지 않으면서 체모가 자라는 반대 방향으로 천천히 계속 움직이십시오.
- 일부 신체 부위에서는 체모가 여러 방향으로 자라날 수 있습니다. 이러한 경우 여러 방향으로 제품을 움직이면 최상의 효과를 얻을 수 있습니다.
- 마사지 기능이 있는 헤어 리프트 액세서리 사용시 마사지 기능과 헤어 리프트 액세서리 빗이 항상 피부에 접촉되어 있는지 확인하십시오.

사용 전 준비

냉동 아이스 젤 패드

아이스 젤 패드는 어린이의 손이 닿지 않는 장소에 보관하십시오 (그림 5).

손상된 아이스 젤 패드는 사용하지 마십시오 (그림 6).

차가움에 상당히 민감하다면 아이스 젤 패드는 사용하지 마십시오.

- 1** 제모하기 전에 쿨링 장갑을 떼어낸 아이스 젤 패드를 냉동고나 냉동실(***)에 2시간 이상 넣어두십시오 (그림 7).

아이스 젤 패드 겉에 물기가 없는지 확인하고 냉동하십시오.

도움말: 아이스 젤 패드를 냉동고에 계속 보관해도 됩니다.

제품 사용

참고: 처음 사용하기 전에 제모 헤드를 청소하십시오.

제품 연결

- 1** 소형 플러그를 제품에 제대로 꽂으십시오 (그림 8).
- 2** 충전기를 벽면 콘센트에 연결하십시오.

쿨링 장갑을 사용하여 다리 털을 제모하십시오.

제모 후 바로 쿨링 장갑을 사용하여 피부를 진정시켜 주십시오.

- 1** 제모할 부위에 오일과 크림 등이 남아있다면 깨끗하게 씻은 후 물기를 닦아내십시오.

- 2** 쿨링 장갑에 아이스 젤 패드를 올려놓고 벨크로 조임을 고정시키십시오 (그림 9).

아이스 젤 패드는 반드시 쿨링 장갑과 함께 사용하십시오.

- 3** 원하는 속도를 선택하고 전원을 켜십시오 (그림 10).

속도는 II로 맞춰 놓고 사용하는 것이 좋습니다. 체모가 거의 없는 부위, 닿기 어려운 부위, 무릎과 발목같이 피부 바로 아래에 뼈가 있는 부위를 제모하려면 속도를 I로 바꾸십시오.

- 4** 최상의 결과를 얻으려면 전원 버튼을 제모기가 움직일 방향으로 두고 제모기를 피부와 수직(90°)이 되게 세운 다음 다른 한 손으로 피부를 잡으십시오 (그림 11).

- 5** 특정 부위를 제모한 후 또는 한 번 사용한 후 쿨링 장갑에 손을 넣고 제모한 부위에 냉각을 시작하십시오 (그림 12).

2분 이상 같은 부위에 쿨링 장갑을 대지 마십시오.

마사지 기능이 있는 헤어 리프트 액세서리를 사용해 제모하십시오.

제모를 처음 하는 경우 마사지 기능이 있는 헤어 리프트 액세서리를 이용해 제모하십시오. 이 액세서리는 피부의 긴장을 완화시키고 제모로 인한 자극을 최소화하여 최상의 헤어 리프트 효과를 나타냅니다.

참고: 체모의 길이가 3-4mm일 때가 제모하기에 가장 쉽고 편리합니다. 체모가 이보다 더 길면 먼저 면도한 다음 1-2주 후에 짧게 자라난 체모를 제모하거나, 빗 액세서리가 장착된 셰이빙 헤드를 사용하여 적절한 길이로 체모를 미리 잘라주는 것이 좋습니다(‘제모 전 빗 액세서리가 장착된 셰이빙 헤드로 체모 미리 자르기’ 섹션 참조).

- 1** 제모할 부위에 데오도란트, 화장품, 크림 등이 남아있으면 깨끗하게 씻은 후 물기를 닦아내십시오.
- 2** 제모 헤드에 마사지 부품이 장착된 헤어 리프트 액세서리를 끼우십시오 (그림 13).
- 3** 상단에 있는 ‘쿨링 글러브로 제모’ 섹션의 3 단계에서 6단계까지 수행하십시오.

거드랑이 및 비키니 라인 면도

비키니 라인 등 민감한 부위를 면도하려면 셰이빙 헤드를 사용하십시오.

참고: 셰이빙 헤드는 속도 설정 I에서만 사용할 수 있습니다.

- 1** 제품 뒷면에서 제모 헤드를 화살표 방향으로 돌려(1) 제품에서 분리하십시오(2) (그림 14).
- 2** 제품에 셰이빙 헤드를 끼우고(1) 제품 뒤쪽에서 화살표 방향으로 돌려(2) 고정하십시오. (그림 15)
- 3** 제품의 전원을 켜십시오. (그림 16)

참고: 속도 II는 셰이빙 헤드가 장착된 경우 작동하지 않습니다.

- 4** 제모기를 들지 않은 손으로 피부를 잡아당기십시오. 거드랑이를 면도할 때는 팔을 들어올리고 피부를 잡아당기십시오.
- 5** 제품을 피부와 수직(90°)이 되게 세우고 전원 스위치가 제품을 움직이려는 방향으로 향하게 하십시오.
- 6** 체모가 자라는 반대 방향으로 제모기를 움직이십시오. (그림 17)

참고: 트리머가 내장된 셰이빙 포일을 피부와 완전히 밀착하는 것이 좋습니다.

- 그림과 같이 비키니 라인을 면도하십시오. (그림 18)
- 그림과 같이 거드랑이를 면도하십시오. 제품을 여러 방향으로 움직여야 합니다. (그림 19)

- 7** 면도를 마치면 제품의 전원을 끄고 셰이빙 헤드를 청소하십시오(‘청소 및 유지관리’란 참조).

- 8** 제품을 보관할 때에는 셰이빙 헤드에 보호 캡을 씌우십시오.

제모 전 빗 액세서리가 장착된 셰이빙 헤드로 체모 미리 자르기

셰이빙 헤드와 빗 액세서리로 비키니 라인의 체모를 4mm 길이로 트리밍하십시오. 10mm 이상의 긴 체모는 트리밍 빗으로 미리 잘라주십시오.

참고: 웨이빙 헤드는 속도 설정 I에서만 사용할 수 있습니다.

- 1 제품 뒷면에서 제모 헤드를 화살표 방향으로 눌러(1) 제품에서 분리하십시오(2) (그림 14).
- 2 제품에 웨이빙 헤드를 끼우고(1) 제품 뒤쪽에서 화살표 방향으로 눌러(2) 고정하십시오 (그림 15).
- 3 웨이빙 헤드에 빗을 끼우십시오 (그림 20).
- 4 ' 거드랑이와 비키니 라인 면도' 섹션의 3단계에서 6단계까지 수행하십시오. 빗 액세서리가 피부에 완전히 밀착되도록 하십시오.

참고: 제품을 피부 위에 너무 수직으로 세우지 마십시오.

- 5 미리 다듬기가 끝나면 제품의 전원을 끄고 웨이빙 헤드를 청소하십시오('청소 및 유지관리' 란 참조).
- 6 제품을 보관할 때에는 웨이빙 헤드에 보호 캡을 씌우십시오.

각질 제거 장갑 사용

샤워시 1주일에 한 번 내지 두 번 각질 제거 장갑을 사용해 피부 속에 체모가 자라는 것을 방지하여 피부를 부드럽고 매끄럽게 만듭니다. 장갑으로 발목부터 무릎까지 원을 그리듯이 고루 문지르십시오.

참고: 제모 전후 24시간 이내에 각질 제거 장갑을 사용하지 마십시오.

세척 및 유지관리

참고: 청소를 시작하기 전에 제품의 전원이 꺼져 있고 전원 플러그가 콘센트에서 분리되어 있는지 확인하십시오.

제품을 세척할 때 수세미, 연마성 세제나 휘발유, 아세톤과 같은 강력 세제를 사용하지 마십시오.

- 절대 제품을 물로 행구거나 수돗물로 세척하지 마십시오 (그림 21).
- 제품과 어댑터에 물이 묻지 않도록 주의하십시오 (그림 22).

쿨링 장갑 세척

- 1 쿨링 장갑에서 아이스 젤 패드를 분리합니다.
- 2 사용 후에는 물에 적신 형광으로 쿨링 장갑을 세척합니다.

참고: 아이스 젤 패드 겔에 물기가 없는지 확인하고 다시 냉동하십시오.

제품 청소

- 1 액세서리를 분리하십시오.
 - 제모 헤드에서 마사지 부품이 장착된 헤어 리프팅 액세서리를 분리하십시오 (그림 23).
 - 웨이빙 헤드에서 빗 부품을 당겨 분리할 수 있습니다 (그림 24).
- 2 액세서리에서 느슨한 체모들을 제거하십시오.
- 3 액세서리를 흐르는 수돗물에서 행구십시오.
- 4 다시 사용하거나 보관하기 전에 액세서리의 물기를 말리십시오.

제모 헤드 청소

- 1 제품 뒷면에서 제모 헤드를 화살표 방향으로 눌러(1) 분리합니다(2) (그림 14).
- 2 청소용 브러시로 느슨한 체모들을 제거하십시오 (그림 25).
- 3 제모 헤드를 흐르는 수돗물에서 5-10초간 행구십시오 (그림 26).
- 4 제모 헤드의 물을 털어내십시오 (그림 27). 제모 헤드의 물을 수건으로 완전히 닦아내십시오.

참고: 제품에 다시 끼우기 전에 제모 헤드가 완전히 말라 있어야 합니다.

웨이빙 헤드 청소

- 1 제품 뒷면에서 웨이빙 헤드를 화살표 방향으로 눌러(1) 분리합니다(2). (그림 28)

- 2 웨이빙 헤드에서 웨이빙 포일을 분리하십시오 (그림 29).
- 3 웨이빙 포일 및 웨이빙 헤드 안쪽을 흐르는 물에서 5-10초간 돌리면서 행구십시오 (그림 30).
- 4 웨이빙 포일과 웨이빙 헤드의 물을 털어내십시오 (그림 31).

참고: 손상 방지를 위해 웨이빙 포일에는 무리한 힘을 가하지 마십시오.

참고: 웨이빙 포일과 웨이빙 헤드를 제품에 다시 장착하기 전에 물기가 완전히 말랐는지 확인하십시오.

- 5 보호 캡을 웨이빙 헤드에 끼우십시오.

도움말: 웨이빙 포일에 1년에 2회 재봉틀용 기름을 한 방울씩 치십시오.

저장

- 제모기, 액세서리 및 어댑터를 보관용 파우치에 보관하십시오.
- 제품을 보관할 때에는 웨이빙 헤드에 보호 캡을 씌우십시오.

교체

제품의 모든 부품은 교체가 가능합니다. 다음 부품을 교체하려면 필립스 대리점 또는 필립스 지정 서비스 센터로 문의하십시오

웨이빙 헤드
웨이빙 헤드를 1주일에 2번 이상 사용할 경우 1년 내지 2년 후 또는 헤드가 손상되었을때 웨이빙 유닛을 교체하십시오.

환경

- 수명이 다 된 제품은 일반 가정용 쓰레기와 함께 버리지 마시고 지정된 재활용 수거 장소에 버리십시오. 이런 방법으로 환경 보호에 동참하실 수 있습니다 (그림 32).
- 아이스 젤 패드가 손상되었다면 일반 가정용 쓰레기와 함께 버리십시오.

품질 보증 및 서비스

보다 자세한 정보가 필요하시거나, 사용상의 문제가 있을 경우에는 필립스전자 홈페이지

(www.philips.co.kr)를 방문하거나 필립스 고객 상담실로 문의하십시오. 전국 서비스센터 안내는 제품 보증서를 참조하십시오. *(주)필립스전자: (02)709-1200 *고객 상담실: (080)600-6600(수신자부담)

보증 제한
웨이빙 헤드는 소모품이므로 보증에 해당되지 않습니다.