PHILIPS

NORELCO

Satin Ice



HP6475
Epilator

7001327

4203 000 31971

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

Read all instructions before using this appliance.

DANGER

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug immediately.
2. Do not use appliance while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place or drop into water or other liquid.
4. Always unplug this appliance from the electrical outlet immediately after using.
5. Unplug this appliance before cleaning.
6. Do not use an extension cord with this appliance.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

1. This appliance should never be used by, on, or near children or invalids. Keep out of reach of children.
2. Use this appliance for its intended household use as described in this manual. Do not use attachments not recommended by Philips Electronics North America Corporation.
3. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an Authorized Norelco Service Location for examination and repair.
4. Keep the appliance, cord and plug away from heated surfaces.
5. Never drop or insert any object into any opening.
6. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
7. Never put the appliance in direct sunlight or store in a pouch at a temperature above140ºF.
8. **Always check rotating discs before use. Do not use this epilator with damaged or broken discs, as injury may occur.**
9. Always check the shaving head foil before use. Do not use if the foil or trimmer is damaged, as injury may occur.
10. Always attach plug to appliance first, then to outlet. Be certain that plug is inserted firmly into appliance. To disconnect, slide switch to OFF position, then remove plug from outlet.
11. To prevent possible damage to the cord, do not wrap cord around the appliance.
12. An appliance should never be left unattended when plugged in.
13. When appliance is on, keep it away from the hair on your head, eyelashes, eyebrows, clothing, brushes, wires and cords to prevent accidents, injury or damage.
14. If you have varicose veins, spots, moles or blemishes, or your skin is sensitive or irritated, or you have in-grown hairs or the tendency towards producing in-grown hairs, do not use this appliance.
15. This appliance is for dry use only.

SAVE THESE INSTRUCTIONS

IMPORTANT: The power plug contains a transformer. Do not cut off the power plug to replace it with another plug, as this will cause a hazardous condition.

Important

- Please read these instructions completely before using this appliance. The following information and precautions are important when using the epilator.
- **CAUTION:** Methods of removing hair by the root can cause ingrown hairs and minor skin injuries. Please consult your doctor if you have any questions about the use of the appliance.
- Do not use the epilator if you suffer from varicose veins, spots, moles or blemishes, or when the skin is irritated, or if you have in-grown hairs or the tendency towards producing in-grown hairs. Consult your doctor first.
- Use of the Satin Ice Epilator may cause reddening or irritation of the skin. This is a normal reaction, which should quickly disappear. However, if irritation remains for more than three days, consult your doctor.

- **Any minor injury resulting from hair removal may allow bacteria to penetrate the injury site potentially causing small scars or a change in pigmentation of the skin. The risk of infection may be minimized by thoroughly cleaning the rotating discs before and/or after each use (see Cleaning section).**
- The Epilator should only be used after prior consultation with your doctor if you have or experience:
  - Open wounds
  - Eczema, psoriasis (scaly eczema), inflamed skin reactions such as folliculitis, skin rashes or the tendency to allergy or allergic reactions
  - Body acne
  - Immune deficiency or disorders
  - Couperose, rosacea, or varicose veins
  - Pregnancy
  - Reduced skin immunity as results of diabetes, pregnancy, Raynaud's disease, etc.
  - Hemophilia
  - If you have moles, raised skin bumps, etc.
- If you have been or begin taking hormone medication, or have recently been pregnant, a change in your hormone levels may influence the thickness, color or amount of hair growth. This is caused by the hormonal changes, not by this method of hair removal.
- **When removing hair from the area behind knees, be sure to keep skin stretched tightly to prevent pinching of the skin by the rotating discs.**
- When using the Epilator for the first time, you may feel some discomfort, irritation or experience reddening of the skin. This is because the hairs are actually removed at the root. The discomfort you feel will tend to lessen with successive uses. You may wish to remove hair in the evening so if any reddening occurs it will diminish overnight.
- To help prevent ingrown hairs, it is recommended to regularly exfoliate the legs at least 2 days before epilating.
- Use only the cord provided.
- Clean appliance regularly following **Cleaning** instructions.

Introduction

Congratulations! Your new Satin Ice Epilator can remove unwanted hairs quickly, easily and effectively. The combination of the proven epilating disc system with the newly developed skin cooler constitutes a revolution in epilation. Thanks to the natural numbing effect of ice on the skin, the new Satin Ice Epilator makes epilation more comfortable. Even short hairs are removed at the root by the quick rotating discs. Any regrowth of hairs tends to be softer - minimizing stubble. Your legs will stay silky smooth and hair-free for weeks. To acquaint yourself with how the Satin Ice Epilator works, be certain to read the instructions and important information contained in this booklet before using for the first time. Satin Ice Epilator with the unique skin cooler... the choice for smooth, silky results that lasts for weeks!

Before Epilating

- Make sure your skin is clean, free from grease and creams. Do not apply any cream before using. Hairs are easier to remove after a bath or shower; but your skin should be completely dry before using your Satin Ice Epilator.
- If you are using the appliance for the first time, it is recommended that you begin at an area with little hair growth to become accustomed to using your Satin Ice Epilator.
- As the hairs are being removed by the root, your skin may feel a little discomfort after using the Satin Ice Epilator system for the first time. This effect will gradually lessen with each use.
- After epilation, regrowth of hairs tends to be softer both in appearance and in touch.
- After each use, you may want to apply a non-alcohol based mild cream or body lotion which helps reduce the possibility of skin irritation.

Freezing the Skin Cooler

1 Remove the protective sleeve from the skin cooler (Fig. 1).

2 Put the skin cooler without the protective sleeve in the freezer cassette and put it in the freezer or freezing compartment for at least 2 hours before you start epilating (Fig. 2).

Make sure the outside of the skin cooler is completely dry before you freeze it.

- Tip: You can store the skin cooler in the freezer permanently.

Features

A Protective Sleeve for Skin Cooler
B Leg Skin Cooler with Pivoting Cooling Head
C Freezer Cassette
D Epilating Head
E Exfoliating Head Protective Cap
F Exfoliating Head
G Shaving Head Protective Cap
H Shaving head
I Appliance
J Adapter
K Cleaning Brush
Storage Pouch
Full 2-Year Warranty
60-Day Money-Back Guarantee

Epilating the Legs

- To help prevent ingrown hairs, it is recommended to regularly exfoliate the legs at least 2 days before epilating.
- Make sure your skin is clean and free of grease and cream. Do not use cream right before you start epilating.

1 Remove skin cooler from freezer cassette. Slide the protective sleeve onto the frozen skin cooler (Fig. 3).

Occasionally the pivoting head freezes onto the skin cooler. The pivoting head will start pivoting again after you have passed it over your leg a few times.

2 Snap the skin cooler onto the appliance (Fig 4).

3 Put the plug into any 120V AC electrical outlet.

4 Switch the appliance ON by selecting the desired speed (Fig. 5).

- Speed I: for areas with little hair growth and/or with bones directly beneath the skin (such as knees and ankles).
- Speed II: for larger areas and/or areas with a thicker hair growth.

5 Stretch your skin tight with your free hand to make the hairs stand upright.

6 Place the appliance on the skin at a right angle, with the cord pointing towards you, and gently move it slowly over the skin against the direction of hair growth (Fig. 6).

Make sure both the epilating discs and the skin cooler touch your skin.
Do not press the appliance onto the skin.

7 Be sure to stretch your leg when you epilate the back of your knee.

8 Switch the appliance OFF by setting the speed selector to position O (Fig 7).

- **It is recommended that the epilator be used on dry legs only.**
- **Note: If you choose to use a cream or moisturizing lotion after use, be certain it does not contain alcohol as it may cause discomfort or irritation.**
- **IMPORTANT: After using the Satin Ice Epilator some redness or irritation may occur. This is normal and should disappear quickly. Clean the appliance regularly following CLEANING instructions.**

Shaving

- Use this epilator for its intended household use as described in this manual.
- Use the shaving head to shave delicate areas, such as your underarms and bikini line.
- Pressing too hard may cause skin irritation.
- Practice is best for optimum results.
- Make sure both trimmers and shaving foil are in complete contact with skin.
- Do not use deodorant or alcohol-based lotions immediately before or after shaving. You may, however, want to use talcum powder.

1 Make sure the appliance is switched Off.


2 Remove the skin cooler from the appliance. You can store the skin cooler in the freezer permanently.


3 Remove the epilating head from the appliance. Press the ribbed sections and slide the epilating head off the appliance in the direction of the arrow (Fig. 8).

4 Place the shaving head on the appliance and move it against the direction of the arrow indicated on the shaving head until it snaps into place (Fig. 9).

The shaving head only fits onto the appliance in one way.

Features





5 Switch the appliance ON by selecting the desired speed.

For best results, it is recommended to use Speed I.

6 Place the shaving head onto your skin and move the appliance slowly and smoothly against the direction of hair growth, while pressing lightly.

Exfoliating

- Use the exfoliating head once or twice a week to improve skin appearance. Only exfoliate legs, not underarms or bikini area.
- Legs should be clean and dry before exfoliating. Do not use cream, foam, gel or lotion before or during exfoliating.
- For best skin appearance, exfoliate before or within 2 days of epilating the legs.
- For hygienic reasons, make sure the exfoliating head is used by only one person.

1 Make sure the appliance is turned Off.

2 Remove the skin cooler from the appliance.

3 Remove the epilating head from the appliance. Press the ribbed sections and slide the epilating head off the appliance in the direction of the arrow (Fig. 8).

4 Place the exfoliating head on the appliance and move it against the direction of the arrow indicated on the exfoliating head until it snaps into place (Fig. 10).

The exfoliating head only fits onto the appliance in one way.

5 Switch the appliance ON by selecting the desired speed.
Depending on your skin type, Speed I or Speed II may be used to exfoliate. We recommend you start using Speed I and if a more intense exfoliation is desired, use Speed II.

6 Place the exfoliating head onto your leg and move the appliance slowly and smoothly over the leg skin.
After exfoliating, you may apply cream or lotion to the legs.

Cleaning

Do not use any corrosive detergents, scouring pads or cloths, petrol, acetone etc to clean any part of this appliance.

- Keep the appliance, plug and cord away from water.

Cleaning the Epilator Head

- Never clean, remove or replace the epilator head when the appliance is on.
- It is essential for hygienic reasons that the epilator head is cleaned after each use.
- Do not apply pressure or touch rotating disc with hard objects as this may dent or damage the discs. If damage occurs, discontinue use immediately.

1 Switch the appliance OFF by setting the switch to 'O' and remove the plug from the outlet (Fig 7).

2 Remove the skin cooler.

3 Slide the protective sleeve off the skin cooler(Fig 3).

4 Clean the appliance, skin cooler and protective sleeve with a moist cloth.

5 Clean the pivoting cooling head of the skin cooler with a brush or moist cloth after each use (Fig. 11).
Make sure the outside of the skin cooler is completely dry before you put it in the provided protective cassette. Return the protective cassette, with the skin cooler inside, to the freezer.

6 Remove the epilating head. Press the ribbed sections and slide the epilating head off the appliance in the direction of the arrow (Fig. 12).

7 Clean all accessible parts and the epilating discs with the brush (Fig. 13).

Never try to detach the epilating discs from the appliance.

8 Slide the epilating head back onto the appliance against the direction of the arrow (Fig.14).
The epilating head only fits onto the appliance in one way.

Cleaning the Shaving Head

- Never clean, remove or replace the shaving head when the appliance is on.
- The shaving head should be cleaned after each use.
- It is recommended to replace the shaving foil and cutter block once a year.
- Do not apply pressure or touch shaving head with hard objects as this may dent or damage foil or trimmers.
- Never use appliance with a damaged or broken foil.

1 Make sure the appliance is switched Off and unplugged.

2 Remove the shaving foil.

3 Clean the hair chamber and the cutter block with the brush (Fig. 15).

To avoid damaging the shaving foil, do not exert any pressure when cleaning.

4 For best shaving performance, it is suggested to lightly oil shaving head twice a year by spreading a drop of mineral oil over the foil and the trimmers.

Replacement parts may be purchased on the Norelco website, www.norelco.com

Cleaning the Exfoliating Head

- Never clean, remove or replace exfoliating head when the appliance is On.
- It is essential for hygienic reasons that the exfoliating head is cleaned after each use.

1 Make sure the appliance is turned Off and unplugged.

2 Remove the exfoliating head by moving it in the direction of the arrow indicated on the exfoliating head.

3 Clean the exfoliating head with the brush while running under tap water (Fig. 16).

Storage

- Be sure appliance is turned off. Remove cord from outlet and epilator before storing in a safe, dry location where it will not be crushed, banged or subject to damage.
- Do not wrap cord around the appliance when storing.
- Store cord in a safe location where it will not be cut or damaged.
- Do not keep appliance permanently plugged into outlet.
- Do not place or store appliance where it can fall or be pulled into a tub or sink, water or other liquid while plugged in.
- Put the protective cap back on the shaving head and exfoliating head after use.
- The appliance and the accessories can be stored in the pouch.
- Put the skin cooler in the freezer cassette and put this cassette in the freezer or in the freezing compartment.

Assistance

For assistance or the Authorized Norelco Service Location nearest you, call toll free:

1-800-243-3050
or visit our website: www.norelco.com

Authorized Norelco Service Location information is available 24 hours a day, 7 days a week.

This appliance has no other user-serviceable parts. Any other service should be performed by an Authorized Norelco Service Location.

Accessories

- Replacement Shaving Foil
  Model HP6116 - For maximum performance, replace shaving foil once a year.
- Replacement Cutter Block
  Model HP2911 - For maximum performance, replace cutter block once a year.
- Replacement parts may be purchased on our website, www.norelco.com

PHILIPS NORELCO

60-DAY MONEY-BACK GUARANTEE

If you are not fully satisfied with your Norelco Satin Ice product, send the product back and we'll refund you the full purchase price.

The product must be shipped prepaid by insured mail, insurance prepaid, and have the sales receipt, indicating purchase price and the date of purchase, enclosed. The product must be postmarked no later than 60 days after the date of purchase. Norelco reserves the right to verify the purchase price of the product and limit refunds not to exceed suggested retail price.

Send dated sales receipt, your complete name and address as indicated below, and the product, prepaid to:

Philips Domestic Appliances
and Personal Care Company
A Division of Philips Electronics
North America Corporation
450 North Medinah Road, Dock 16
Roselle, IL 60172-2329

Please allow 4-6 weeks for delivery of check.
(Please Print)

Name_____

Address_____

City_____

State _____Zip_____

Daytime Telephone No. (_____)_____
AREA CODE

Email Address:_____

REASON FOR RETURNING:_____

Full Two-Year Warranty

Philips Electronics North America Corporation warrants each new Norelco product, Model HP6475, against defects in materials or workmanship for a period of two years from the date of purchase, and agrees to repair or replace any defective product without charge. **IMPORTANT:** This warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, the affixing of any attachment not provided with the product or loss of parts or subjecting the product to any but the specific voltage.* Use of unauthorized replacement parts will void this warranty.

PHILIPS ELECTRONICS NORTH AMERICA CORPORATION WILL NOT PAY FOR WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE AND WILL NOT REIMBURSE THE CONSUMER FOR DAMAGE RESULTING FROM WARRANTY SERVICE PERFORMED BY A NON-AUTHORIZED REPAIR SERVICE.

NO RESPONSIBILITY IS ASSUMED FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

In order to obtain warranty service, simply take or ship the product postage prepaid to the nearest Authorized Norelco Service Location. It is suggested that for your protection you return shipments of product by insured mail, insurance prepaid. Damage occurring during shipment is not covered by this warranty. **NOTE:** No other warranty, written or oral, is authorized by Philips Electronics North America Corporation. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion and limitations may not apply to you.

*Read enclosed instructions carefully.

Manufactured for:
Philips Domestic Appliances and Personal Care Company
A Division of Philips Electronics North America Corporation
1010 Washington Blvd., Stamford, CT 06912-0015



This symbol on the product's nameplate means it is listed by Underwriters Laboratories, Inc.

Norelco is a Registered Trademark of Philips Electronics North America Corporation.
Satin Ice is a Trademark of Philips Electronics North America Corporation.

PHILIPS is a Registered Trademark of Koninklijke Philips Electronics N.V.

© 2005 Philips Electronics North America Corporation. All Rights Reserved.