

PHILIPS

Pouch

for shavers S5xxx-S7xxx-S9xxx

CP9062



A pouch to safely store your shaver.

This plastic pouch allows you to hygienically store your shaving device. The bag is also useful for taking your shaver with you when you're on the move.

Specifications

Replaceable part

Fits product types:: S9021, S9031, S9041, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9311, S9321, S9371, S9511, S9521, S9522, S9531, S9711, S9712, S9721, S9731, S9911

Fits product type: S5400/41, S5620/12, S5620/41, S9021/12, S9021/13, S9031/12, S9031/13, S9031/26, S9031/27, S9041/12, S9041/13, S9111/12, S9111/26, S9111/31, S9111/32, S9111/41, S9111/42, S9112/43, S9151/31, S9151/41, S9151/42, S9161/31, S9161/32, S9161/41, S9161/42, S9171/31, S9171/32, S9181/13, S9511/31, S9511/32, S9511/41, S9511/42, S9511/63, S9521/31, S9521/32, S9521/41, S9711/31, S9711/32, S9911/10, S9911/11, S9911/33, S9911/62, S9988/68, S5008, S5010, S5011, S5013, S5015, S5050, S5070, S5075, S5077, S5078, S5079, S5080, S5081, S5420/04, S5420/06, S5420/08, S5510/37, S5510/45, S5520/45, S5600/12, S5600/41, S5085, S5205, S5290, S5355, S7310, S7311, S7320, S7370, S7510, S7520, S7530, S7550, S7710, S8950, S9090, S9181, S9182, S9512, S9522, S9988, S5090, S5095, S5210, S5211, S5230, S5270, S5271,

S5340, S5360, S5370, S5380, S5390, S5391
Fits product type:: S5100, S5110, S5130, S5140, S5150, S5210, S5211, S5230, S5270, S5271, S5310, S5320, S5330, S5340, S5360, S5370, S5380, S5390, S5391, S5400, S5420, S5510, S5520, S5560, S5570, S5600, S5610, S5620, S5082, S5085, S5090, S5095, S7720, S7780, S7920, S9021, S9031, S9041, S9051, S9111, S9112, S9121, S9151, S9152, S9161, S9171, S9181, S9182, S9185, S9186, S9311, S9321, S9371, S9511, S9512, S9521, S9522, S9531, S9551, S9552, S9711, S9712, S9721, S9731, S9732, S9741, S9751, S9781, S9911, S9981, S9988, S5290, S5571, S7310, S7311, S7312, S7320, S7330, S7370, S7510, S7520, S7530, S7540, S7550

Fits product family: S5082, S5086, S5091, S5212, S5213, S5231, S5251, S5252, S5272, S5273, S5290, S5335, S5355, S5395, S5396, S7310, S7320, S7371, S7510, S7521, S7522, S7530, S7550, S7720, S7920, S8860, S8880, S8980, S9211, SP9811, SP9851

Fits shaver type:: S7310, S7311, S7320, S7340, S7350, S7360, S7370, S7371, S7510, S7520, S7521, S7522, S7530, S7550, S7560, S7561, S7710, S7720, S7730, S7740, S7780, S7920,

S7921, S7980, S8950, S8960, S8980, S9031, S9041, S9051, S9090, S9091, S9111, S9112, S9131, S9151, S9161, S9171, S9181, S9185, S9186, S9211, S9311, S9521, S9531, S9551, S9552, S9711, S9721, S9732, S9733, S9741, S9751, S9781, S9911, SP9820, SP9821, SW5700, SW5710, SW5720, SW6700, SW6710, SW9700, S5672, S5008, S5010, S5011, S5013, S5015, S5040, S5050, S5051, S5070, S5071, S5072, S5073, S5074, S5075, S5076, S5077, S5078, S5079, S5080, S5081, S5082, S5083, S5085, S5086, S5090, S5091, S5095, S5100, S5110, S5120, S5130, S5140, S5150, S5205, S5210, S5211, S5212, S5213, S5214, S5215, S5216, S5230, S5231, S5240, S5250, S5251, S5252, S5270, S5271, S5272, S5273, S5290, S5310, S5320, S5330, S5340, S5351, S5355, S5360, S5361, S5370, S5380, S5390, S5391, S5395, S5396, S5397, S5400, S5420, S5510, S5520, S5530, S5540, S5550, S5551, S5560, S5570, S5571, S5572, S5580, S5590, S5600, S5610, S5620, S5630, S5640, S5650, S5651, S5660, S5670

