PHILIPS

shaving foil

StyleShaver

QS6100/53







Keep a perfect style

Change foil every 12 months for best results

Easy to use

Dual shaver with trimmer shaves even the toughest beards

Brings maximum ease of use

100% waterproof for use in the shower and easy cleaning

Replace and renew

Change foil every 12 months for best results

shaving foil

QS6100/53

Highlights

100% waterproof




Trim and shave where you want to, wet or dry. And when you're done, just rinse it off under the tap.

Dual foil shaver with trimmer



The dual foil shaver makes it easy to clean up stubble around your beard, even on your neck. The mid trimmer catches longer, tougher hairs and the 2 floating foils shave everything else perfectly smooth.

Change foil every 12 months



1. detach the shaver end of your Styleshaver. 2. Remove the old foil and cutters. 3. Place the new foil in the holder. 4. Place the new cutters into your Styleshaver and then click on the new holder and foil.

Specifications

Shaving foil

Fits product types: QS6140, QS6160 Shaving foil per packaging: 1

© 2018 Koninklijke Philips N.V. All Rights reserved. Issue date 2018-12-10 Version: 2.1.1



Specifications are subject to change

without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com