



Philips
Sensitive Skin Cleansing
Brush

Replace every 3 months

For daily use
Normal to sensitive skin
Easy to replace



SC5991/00

Replacement Brush Head for Sensitive Skin

For clean and soft skin

Replacement Brush Head specifically designed for Sensitive Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- For optimal results, replace the brush every three months
- Click-on brush head; easy to put on and take off

Developed for sensitive skin types

- Ultra soft bristles for a more effective, gentle cleaning



asimpleswitch.com

PHILIPS

Sensitive Skin Cleansing Brush

Replace every 3 months For daily use, Normal to sensitive skin, Easy to replace

Specifications

Benefits

- Type of skin: For sensitive skin

Ease of use

- Compatible with: Philips VisaPure Essential

- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

Service

- Warranty: 2-year limited warranty

SC5991/00

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time

For optimal results, replace the brush every three months

Brush Bristles

The specially designed filaments are even thinner and softer than those of the normal brush head to deliver an even softer and delicate cleansing experience specific for sensitive skin.



Issue date 2017-12-24

Version: 6.0.1

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com