



Philips  
Normal Skin Cleansing  
Brush

Replace every 3 months

For daily use  
For normal to oily skin  
Easy to replace



SC5990/00

## Replacement Brush Head for Normal Skin

For clean and soft skin

Replacement Brush Head for Normal Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

**Developed for normal to oily skin types**

- 17000 soft bristles for deep skin cleansing

**Easy to maneuver to focus on hard-to-reach areas**

- Perfect size and shape to easily reach all face areas

**Easy to replace**

- Click-on brush head; easy to put on and take off
- For optimal results, replace the brush every three months



asimpleswitch.com

**PHILIPS**

## Normal Skin Cleansing Brush

Replace every 3 months For daily use, For normal to oily skin, Easy to replace

# Specifications

### Benefits

- Type of skin: For all skin types

### Ease of use

- Compatible with: Philips VisaPure Essential

- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

### Service

- Warranty: 2-year limited warranty

SC5990/00

# Highlights

### Size and shape

Perfect size and shape to easily reach all face areas

### Brush Bristles

17000 soft filaments gently massage and deeply cleanse the skin like 17000 fingers.

### Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

### Long operating time

For optimal results, replace the brush every three months



Issue date 2017-12-24

Version: 6.0.1

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)