

PHILIPS

Normal Skin Cleansing Brush

Replace every 3 months

For daily use

For normal to oily skin

Easy to replace



SC5990/00



Replacement Brush Head for Normal Skin

For clean and soft skin

Replacement Brush Head for Normal Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Developed for normal to oily skin types

- 17000 soft bristles for deep skin cleansing

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- Click-on brush head; easy to put on and take off
- For optimal results, replace the brush every three months



asimpleswitch.com

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Brush Bristles

17000 soft filaments gently massage and deeply cleanse the skin like 17000 fingers.

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time

For optimal results, replace the brush every three months

Specifications

Benefits

Type of skin: For all skin types

Ease of use

Compatible with: Philips VisaPure Essential

Replacement: Easy snap-on brush head

Recommended replacement: Every 3 months

Service

Warranty: 2-year limited warranty



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.