

PHILIPS

Dry electric shaver,
Series 1000

Shaver series 1000

PowerCut Blades

One-touch open

Corded and cordless use



S1333/41



Clean shave, without fuss

Philips Shaver Series 1000 gives you an easy and convenient shave at an accessible price with self-sharpening PowerCut blades and full washability.

Easy to use

- One-touch open for easy cleaning
- Keep your charge in check
- Designed for optimum handling
- Water-resistant for easy cleaning
- 45 minutes of cordless shaving from a 1 hour charge
- Use with or without a cord
- Keep your shaver covered between shaves

A comfortable shave

- Glides over skin for a comfortable, even shave
- Glides over your skin for a smooth and even finish
- Follows the contours of your face

Get the most out of your shaver

- Even up your moustache and sideburns
- A 5 minute power boost for short-notice shaving

Highlights

PowerCut Blades



The Philips shaver glides over your skin for a clean and comfortable finish. Its 27 PowerCut blades cut each hair right above skin level, giving you a smooth and even shave, every time.

4D Flex Heads



This shaver is designed to maintain even contact with your skin without nicking it. The 4D Flex Heads flex and float in 4 directions for a clean shave every time.

One-touch open



Clean your electric shaver with the touch of a button. Simply flip open the shaver head and rinse with water.

Corded and cordless use



Use your convenient cordless shaver for tangle-free grooming. Or plug it in for a reliable corded shave when the battery is empty.

1-level battery indicator



Use the intuitive indicator to see when the shaver battery is running low, empty or fully charged.

45 minutes of cordless shaving



Shave cordlessly for up to 45 minutes after a 1 hour charge. Or shave with the power cord plugged in when the battery is empty.

5 minute quick charge



In a hurry? Just plug in your shaver for 5 minutes and get enough power for 1 full shave.

27 self-sharpening blades



The 27 self-sharpening blades on this electric shaver have been precision-engineered for a consistently clean shave.

Pop-up trimmer



Refine and define your moustache and sideburns with the pop-up trimmer—and complete your look with ease.

Specifications

Accessories

Maintenance: Protective cap

Power

Run time: 45 minutes

Charging: 1 hour full charge, 5-min quick charge

Battery Type: NiMH

Automatic voltage: 100–240 V

Design

Colour: Twist Red

Handle: Ergonomic grip and handling, Non-slip rubber handle

Service

Replacement head: Replace every 2 yrs with SH30

2 year warranty

Shaving Performance

Contour following: 4-direction Flex Heads

Shaving system: PowerCut blade system

Ease of use

Display: 1 level battery indicator

Cleaning: One-touch open, Fully washable

Operation: Corded and Cordless use

Dry: Shave Dry

