

PHILIPS

Dry electric shaver,
Series 1000

Shaver series 1000

PowerCut Blades

One-touch open

Corded and cordless use

S1332/41



Clean shave, Without fuss

Philips Shaver Series 1000 gives you an easy and convenient shave at an accessible price with self-sharpening PowerCut blades, and full washability.

Easy to use

- One-touch open for easy cleaning
- Keep your charge in check
- Designed for optimum handling
- Keep your shaver covered between shaves
- 45 minutes of cordless shaving from a 1-hour charge
- Use with or without a cord
- Water-resistant for easy cleaning

A comfortable shave

- Glides over your skin for a smooth and even finish
- Glides over skin for a comfortable, even shave
- Follows the contours of your face

Get the most out of your shaver

- A 5-minute power boost for short notice shaving
- Even-up your mustache and sideburns

Highlights

PowerCut Blades



The Philips shaver for a clean and comfortable finish. Its 27 PowerCut blades cut each hair right above skin level, giving you a smooth and even shave, every time.

4D Flex Heads



The shaver designed to maintain even contact with your skin without nicking it. The 4D Flex Heads flex and float in 4 directions for a clean shave every time.

5-minute quick charge



In a hurry? Just plug in your shaver for 5 minutes and get enough power for 1 full shave.

One-touch open



Clean your electric shaver with the touch of a button. Simply flip open the shaver head and rinse with water.

45 minutes of cordless shaving



Shave cordlessly for up to 45 minutes after a 1-hour charge. Or shave with the power cord plugged in when the battery is empty.

27 self-sharpening blades



The 27 self-sharpening blades on this electric shaver have been precision-engineered for a consistently clean shave.

Corded and cordless use



Use your convenient cordless shaver for tangle-free grooming. Or plug it in for a reliable corded shave when the battery is empty.

1-level battery indicator



Use the intuitive indicator to see when the shaver battery is running low, empty, or fully charged.

Pop-up trimmer



Refine and define your mustache and sideburns with the pop-up trimmer—and complete your look with ease.

Specifications

Accessories

Maintenance: Protective cap

Power

Battery Type: NiMH

Charging: 1 hour full charge, 5 min quick charge

Run time: 45 minutes

Automatic voltage: 100–240 V

Design

Handle: Ergonomic grip & handling, Non-slip rubber handle

Color: Shiny Black

Service

2-year warranty

Replacement head: Replace every 2 yrs with SH30

Shaving Performance

Shaving system: PowerCut blade system

Contour following: 4-direction Flex Heads

Ease of use

Display: 1 level battery indicator

Cleaning: One-touch open, Fully washable

Operation: Corded & Cordless use

Dry: Shave Dry

