

Philips
Normal Skin Cleansing
Brush

Replace every 3 months

For daily use
For normal to oily skin
Easy to replace



SC5990/00

Replacement Brush Head for Normal Skin

For clean and soft skin

Replacement Brush Head for Normal Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Developed for normal to oily skin types

- 17000 soft bristles for deep skin cleansing
- Perfectly designed for optimal hygiene

Easy to maneuver to focus on hard-to-reach areas

- Perfect size and shape to easily reach all face areas

Easy to replace

- For optimal results, replace the brush every three months
- Click-on brush head; easy to put on and take off

PHILIPS

Normal Skin Cleansing Brush

Replace every 3 months For daily use, For normal to oily skin, Easy to replace

Specifications

Benefits

- Type of skin: For all skin types

Service

- Warranty: 2-year limited warranty

Ease of use

- Compatible with: Philips VisaPure Essential
- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

SC5990/00

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Brush Bristles

17000 soft filaments gently massage and deeply cleanse the skin like 17000 fingers.

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time

For optimal results, replace the brush every three months

Designed for optimal hygiene



The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.



Issue date 2024-01-14

Version: 7.0.1

EAN: 87 10103 78523 1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com