

Brush

Replace every 3 months For daily use Normal to sensitive skin Easy to replace



SC5991/00

Replacement Brush Head for Sensitive Skin

For clean and soft skin

Replacement Brush Head specifically designed for Sensitive Skin care. For use only with Philips VisaPure Essential facial cleansing brush.

Easy to maneuver to focus on hard-to-reach areas

• Perfect size and shape to easily reach all face areas

- For optimal results, replace the brush every three months
- · Click-on brush head; easy to put on and take off

Developed for sensitive skin types

- Ultra soft bristles for a more effective, gentle cleaning
- · Perfectly designed for optimal hygiene



Specifications

Benefits

• Type of skin: For sensitive skin

Service

• Warranty: 2-year limited warranty

Ease of use

- Compatible with: Philips VisaPure Essential
- Replacement: Easy snap-on brush head
- Recommended replacement: Every 3 months

Highlights

Size and shape

Perfect size and shape to easily reach all face areas

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Long operating time
For optimal results, replace the brush every three months

Brush Bristles

The specially designed filaments are even thinner and softer than those of the normal brush head to deliver an even softer and delicate cleansing experience specific for sensitive skin.

Designed for optimal hygiene



The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.



Issue date 2024-01-14

© 2024 Koninklijke Philips N.V.

All Rights reserved. Version: 7.0.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 87 10103 78524 8

www.philips.com