



Philips Beardtrimmer
series 7000
Vacuum Beard Trimmer

0.5mm precision settings
Full Metal Trimmer
60 min cordless use/1h charge
Captures up to 90% cut hair*



BT7206/13

Less mess vacuum trimmer

Integrated vacuum captures up to 90% cut hair*

Trim your beard, mustache and sideburns while keeping tidy with this trimmer. Its powerful vacuum catches cut hair as you go along, giving you a mess-free trim.

Easy to use

- Lights indicate when battery is low, empty, full or charging
- 60 minutes run time after a 1-hour charge or plug it in
- Adjusts to different length settings

Even trimming results

- Lifts and guides hairs for an effortless even trim

PHILIPS

Specifications

Create the look you want

- Number of length settings: 20 integrated length settings

Cutting system

- Cutting element: Stainless steel blades
- Range of length settings: 0.5 up to 10 mm
- Precision (size of steps): By 0.5 mm

Design

- Color: Black

Ease of use

- Zoom wheel: Easily adjust length settings
- Cleaning: Rinseable attachments

- Display: Battery light
- Operation: Corded & Cordless use

Accessories

- Maintenance: Cleaning brush
- Pouch: Storage pouch

Power

- Battery Type: NiMH
- Automatic voltage: 100-240 V
- Run time: 60 minutes
- Charging: 1 hour full charge

Service

- 2-year guarantee
- No oil needed

Highlights

Innovative lift & trim system

Trim your stubble in one quick stroke. Our innovative lift & trim system raises each hair, then guides it toward the double-sharpened stainless steel blades. The result is an even stubble or trim in just one go.

20 lock-in length settings

Cut to the exact length you're after. Just spin the precision dial to one of 20 length settings between 0,5 - 10mm in 0.5mm increments.

Corded and cordless use

Charge your beard trimmer for 1 hour to get 60 minutes of cordless use. If you need more energy while trimming, you can simply plug the trimmer into the wall. This trimmer has been designed to run both cordless and plugged in.

Battery indicators

The battery indicators in this trimmer let you know what your battery status is: Low, empty, charging or full. This way, you can charge your trimmer on time and fully, so you won't end up with an empty battery in the middle of your trim.

