

Philips VisaPure
Normal Skin Cleansing
Brush

For normal to oily skin

For daily use
Replace every 3 months
Easy to replace



SC5990/10

Brush head for normal skin

For clean and soft skin

The Normal brush head is ideal for normal, oily and combination skin types. The brush has 17.000 soft bristles, with a unique bristle technology to remove 10x more impurities and dead skin cells than your hands while being just as gentle.

Developed for normal to oily skin types

- Perfectly designed for optimal hygiene

Easy to replace

- Click-on brush head; easy to put on and take off
- Replace every 3 months

Deep gentle cleansing

- Increases the absorption of your favorite skincare products

5-in-1 bristle technology

- Unique composition of face cleansing brush bristles

PHILIPS

Normal Skin Cleansing Brush

For normal to oily skin For daily use, Replace every 3 months, Easy to replace

Specifications

Benefits

- Type of skin: For normal, combination and oily skin types

Ease of use

- Replacement: Easy click-on brush head
- Recommended replacement: Every 3 months
- Waterproof: Can be used in the shower

- Easy to clean
- Use with cleansing product

Service

- Warranty: 2-year limited warranty

Compatibility

- Use with all VisaPure models

SC5990/10

Highlights

Increases absorption of creams



Cleansing with VisaPure means that you remove more make up residue and dull and dead skin cells. Thanks to the deep cleansing effect, your favorite skincare products such as creams, serums and essences are better absorbed by the skin.

Face cleansing brush bristles

All VisaPure brushes have unique 5-in-1 bristle technology. Each bristle is polished twice and silky soft ends ensure a smooth glide. VisaPure bristles are extra long for absolute skin comfort. To ensure efficacy, VisaPure bristles are up to 3x smaller than your pores and dense brush reach more pores in one treatment to give a soft, luxurious feel whilst cleansing. The bristle material is specially selected to be water resistant.

Click-on brush head

Simply click on or click off the brush head. Easy to fit, our brush heads are compatible across all Visapure models.

Replace every 3 months

For best results, replace the brush every 3 months. The brush is easy to replace by simply pulling off the brush from the device.

Designed for optimal hygiene



The silky soft bristle material of all our VisaPure brush heads is a specially chosen, delicate nylon. This helps to ensure the brush heads are super easy to clean and keep fresh.



Issue date 2022-06-16

Version: 9.0.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com