

Philips Viva Collection
Pusher incl. lid



CP1324

to replace your current Pusher incl. lid

you need the pusher to pull down all the ingredients

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types:: HR1855/01, HR1855/03, HR1855/05, HR1855/30, HR1855/31, HR1855/40,

HR1855/45, HR1856/00, HR1863/00, HR1863/01, HR1863/03, HR1863/05, HR1864/00

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2022-06-18

Version: 7.7.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com