

PHILIPS

Dry electric shaver

2 Heads Shaver

ComfortCut Blade System

4-direction Flex Heads

SW170/04



Close & easy

Wield the force!

Choose the path to a close, easy shave. Our ComfortCut blades with rounded profile heads glide smoothly over your skin for a protective shave.

Adjusts to every curve of your face and neck

- Heads flex in 4 directions to easily shave every curve

Easy to use

- Shaver can be rinsed clean under the tap
- Design for finer grip
- 2-year guarantee, worldwide voltage and replaceable blades
- 20 minutes of cordless shaving

A comfortable shave

- Rounded edges move smoothly over skin for a protective shave

Highlights

ComfortCut Blade System

Get a comfortable shave, wet or dry. Our ComfortCut Blade System with rounded profile heads glide smoothly across your skin while protecting it from nicks and cuts.

4-direction Flex Heads



Flex heads with 4 independent movements adjust to every curve of your face, giving you an easy shave even on the neck and jaw line.

20 minutes of cordless shaving



You'll have 20+ minutes of running time – that's about 5 shaves – on a ten-hour charge. This shaver only operates in cordless mode.

Fully washable shaver



Simply open the shaver head to rinse it thoroughly under the tap.

Anti slip grip



Unique ergonomic grip ensuring complete control and extra precision.

Built to last



All of our shavers come with a 2-year worldwide guarantee and can adapt to any voltage. The long-lasting blades only need to be replaced after 2 years.

Specifications

Accessories

Maintenance: Protective cap

Power

Automatic voltage: 100-240 V

Battery Type: NiMH

Charging: 10 hours full charge

Run time: 20 min / 5 shaves

Stand-by power: < 0.25 W

Max power consumption: 9 W

Design

Color: Star Wars StormTrooper

Handle: Anti-slip grip

Service

Replacement head: Replace every 2 yrs with SH30

2-year guarantee

Shaving Performance

Shaving system: ComfortCut Blade System

Contour following: 4-direction Flex Heads

Ease of use

Cleaning: Fully washable

Operation: Cordless use, Unplug before use

