

PHILIPS

wet and dry electric
shaver

CareTouch

GentleCut heads

Flexing heads

AT799/16



Smooth on skin, tough on ingrown hairs

The Philips CareTouch shaver is designed to help reduce ingrown hairs to give you smooth skin every day. With Aquatec Wet & Dry you can enjoy a refreshing wet shave when used with gel or foam or a convenient shave when used dry.

Easy to use

- Lithium-Ion battery for long-lasting power
- Battery low, battery full and charging indicator
- Fully washable: Simply rinse under the tap
- Up to 45 minutes of cordless power

A smooth shave for a confident look

- Aquatec Wet and Dry - Refreshing wet shave or an easy dry shave
- Rotary Comfort System effortlessly glides over your skin

Our best shaver for ingrown hairs

- GentleCut heads cut just above skin level for smooth skin

Convenient trimming

- Pop-up trimmer: Perfect for sideburns and moustaches

Highlights

GentleCut heads



Gently cut just above skin level for smooth skin.

Aquatec Wet and Dry



Shave wet with gel or foam for extra skin protection or dry for convenience.

Rotary Comfort System



Effortlessly glides over your skin for enhanced comfort and smoothness.

Pop-up trimmer




The full width, pop-up trimmer is perfect for grooming your sideburns and moustache.

Lithium-Ion Battery



Lithium-Ion battery for long-lasting power

Cordless use only



Up to 45 minutes of cordless power. Fully charges in 8 hours or 3-minute quick charge for 1 shave.

Battery light



Battery low, battery full and charging indicator

Fully washable



Fully washable: Simply rinse under the tap

Specifications

Accessories

Maintenance: Protective cap
Power cord

Power

Run time: 45 minutes
Charging: Rechargeable, 8 hours full charge
Automatic voltage: 100–240 V

Service

Replacement head: HQ8 has been replaced by SH50, Replace every 2 yrs with SH50 (these have replaced HQ8)
2 year guarantee

Shaving Performance

Contour following: Rotary comfort system
SkinComfort: Aquatec Wet and Dry
Shaving system: GentleCut heads
Styling: Pop-up trimmer

Ease of use

Display: Battery full indicator, Battery low indicator, Charge indicator, 1 LED indicator
Operation: Cordless use

