

PHILIPS

Sonicare Brush
heads

Sensiflex

4-pack

HX2014



Sensiflex replacement brushes

Sonicare toothbrush replacement head

Sensiflex replacement brushes. Replace the brush head of your Philips Sonicare electric toothbrush every 6 months for optimal performance.

Double Cleaning Action

- Naturally whiter teeth
- Cleans visible teeth surfaces

Gentle on gums, tough on plaque

- Gum Protection system

Highlights

Gum Protection system



Philips Sonicare's patented Gum Protection system adjusts to maintain optimal brushing pressure

Double Cleaning Action



Cleans visible teeth surfaces while the active tip targets hard-to-reach plaque in between teeth.

Naturally whiter teeth



Naturally whiter teeth

Specifications

Cleaning performance

Brush heads: 4

