

PHILIPS

Wet or Dry electric shaver

Shaver series 1000

ComfortCut blades

3-Directional Flex Heads

One-touch open

Pop-up trimmer



S1323/41



Fresh shave, Smooth finish

Philips AquaTouch shaver 1000 gives you an affordable, smooth and refreshing wet or dry shave with self-sharpening ComfortCut blades.

Easy to use

- One-touch open for easy cleaning
- Keep your charge in check
- 5-minute quick charge
- Designed for optimum handling
- 45 minutes of cordless shaving from a 1-hour charge

A comfortable shave

- 3D Floating Heads move for a convenient clean shave
- Glides over skin for a smooth and even shave

Get the most of your shaver

- Even-up your mustache and sideburns

AquaTouch

- Glides over skin for a comfortable, even shave
- Aquatec for a refreshing wet or convenient dry shave
- Skin Protection System allows smooth gliding to protect skin

Highlights

ComfortCut Blades



Get a clean, comfortable shave with this Philips shaver. This electric shaver's 27 ComfortCut blades cut each hair right above skin level to give you a smooth and even finish.

3D Floating Heads



Get a convenient, clean shave with the 3-directional floating heads. They move to adjust to the curves of your face, creating smooth contact with your skin without a lot of pressure.

Aquatec Wet or Dry



Get a convenient dry shave or a more comfortable wet shave with gel or foam, even in the shower.

One-touch open



Clean your electric shaver with the touch of a button. Simply flip open the shaver head and rinse with water.

1-level battery indicator



Use the intuitive indicator to see when the shaver battery is running low, empty, or fully charged.

45 minutes of cordless shaving



Shave cordlessly for up to 45 minutes after a 1-hour charge. The shaver only operates when not charging.

5-minute quick charge




In a hurry? Plug in your shaver for 5 minutes and get enough power for 1 full shave.

27 self-sharpening blades



The 27 self-sharpening blades on this electric shaver have been precision-engineered for a consistently clean shave.

Pop-up trimmer



Refine and define your mustache and sideburns with the pop-up trimmer—and complete your look with ease.

Ergonomic design



Handle your Philips shaver with confidence thanks to an ergonomic design created for optimum grip.

Specifications

Accessories

Maintenance: Protective cap

Power

Run time: 45 minutes

Charging: 1 hour full charge

Battery Type: NiMH

Automatic voltage: 100-240 V

Design

Color: Adriatic Blue

Handle: Ergonomic grip & handling, Non-slip rubber handle

Service

Replacement head: Replace every 2 yrs with SH30

2-year warranty

Shaving Performance

Contour following: 3-direction Flex Heads

Shaving system: ComfortCut Blade System

Styling: Pop-up trimmer

Ease of use

Display: 1 level battery indicator

Wet & Dry: Shave wet or dry

Cleaning: One-touch open, Fully washable

Operation: Unplug before use, Cordless use only

